Manualslib.com - The Global Manuals Library

JVC LT-32D200 USER MANUAL

Quick Links

Control Panel
Remote Control Function
Tv Screen Display Mode
Troubleshooting Guide

Table of Contents

Important Safety Instructions
Precautions
Trademark Information
INTRODUCTION
Supplied Accessories
Attaching the Stand
Symbols Used in this Manual
Features
Table of Contents
Control Panel
Terminals
Remote Control Function
Installing the Batteries
PREPARATION
Antenna Connection
Connection to Cable Receiver or Satellite Box
External Device Connection
Cable Management
Plug In the AC Power Cord
Initial Setup
WATCHING TV
Channel Selection
Volume Adjustment
Sleep Timer
Still Mode
Switching Each Input Mode
Switching Audio Mode
TV Screen Information
TV Screen Display Mode
OPTIONAL SETTING
Main Menu
Autoscan
Channel List
Manual Register
Antenna Confirmation
Language Selection

Picture Adjustment
Sound Adjustment
Closed Caption
Caption Service
Digital Caption Service
background opacity
background color
font style
Child Lock
Channel Lock
MPAA Rating
New Password
PC Settings
Energy Saving Mode
Location
Current Software Info
OPERATING DVD
Playable Media
Unplayable Media
Playback
Disc Menu
Resume Playback
Paused and Step-by-step Playback
Fast Forward / Fast Reverse
Slow Forward / Slow Reverse
Zoom
Search Functions
Time Search
Direct Search
Repeat Playback
Repeat A-B Playback
Random Playback
Programmed Playback
On-screen Display
Special Settings
Camera Angles
Audio Language
Black Level Setting
virtual surround
Stereo Sound Mode
Marker Setup

DVD SETTING
DVD Language Setting
DVD Audio Setting
Parental Setting
Others
Reset to the Default Setting
Language Code List
TROUBLESHOOTING
FAQ
Troubleshooting Guide
Glossary
Maintenance
Cable Channel Designations
General Specifications
Electrical Specification
Other Specifications
Other ManualsLib Projects

Español | Français | English

JVC

LCD Television Built-in DVD Player Users Guide

LT-32DV20
LT-32D200

32" class (31.5" Diagonal)

HDTV HIGH DEFINITION TELEVISION

HDMI HIGH-DEFINITION MULTIMEDIA INTERFACE

DOLBY DIGITAL

ENERGY STAR

Important Note:

In the spaces below, enter the model and serial number of your television (located at the rear of the television cabinet). Staple your sales receipt or invoice to the inside cover of this guide. Keep this user's guide in a convenient place for future reference. Keep the carton and original packaging for future use.

Model No: _____

Serial Number: _____

0209TKH-FU-FU

☑ Precautions

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.
APPARATUS SHALL NOT BE EXPOSED TO DRIPPING OR SPLASHING AND NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS.

CAUTION
RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the apparatus's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the apparatus.

The caution marking is located on the rear or bottom of the cabinet.

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not place the unit on the furniture that is capable of being tilted by a child and an adult leaning, pulling, standing or climbing on it. A falling unit can cause serious injury or even death.

FCC WARNING
This apparatus may generate or use radio frequency energy. Changes or modifications to this apparatus may cause harmful interference unless the modifications are expressly approved in the manual. The user could lose the authority to operate this apparatus if an unauthorized change or modification is made.

RADIO-TV INTERFERENCE
This apparatus has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This apparatus generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this apparatus does cause harmful interference to radio or television reception, which can be determined by turning the apparatus off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1) Reorient or relocate the receiving antenna.
2) Increase the separation between the apparatus and receiver.
3) Connect the apparatus into an outlet on a circuit different from that to which the receiver is connected.
4) Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

This apparatus should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided. Make sure to leave a space of 3.2 inches (8cm) or more around this apparatus.

Disconnect the mains plug to shut off when find trouble or not in use. The mains plug shall remain readily operable.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
WARNING: Batteries (battery pack or battery installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

(Hg) LAMP IN LCD CONTAINS MERCURY, DISPOSE ACCORDING TO LOCAL, STATE OR FEDERAL LAW.

WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the instructions.

LASER SAFETY

This unit employs a laser. Only a qualified service person should remove the cover or attempt to service this device, due to possible eye injury.

CAUTION:USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION:VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCK DEFEATED. DO NOT STARE INTO BEAM.

LOCATION:INSIDE, NEAR THE DECK MECHANISM.

IMPORTANT COPYRIGHT INFORMATION

Unauthorized copying, broadcasting, public performance and lending of discs are prohibited. This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

TO AVOID THE HAZARDS OF ELECTRICAL SHOCK AND FIRE

- Do not handle the AC power cord with wet hands.
- Do not remove this unit's cabinet. Touching parts inside the cabinet could result in electric shock and/or damage to this unit. For service and adjustment inside the cabinet, call a qualified dealer or an authorized service center.
- Do not pull on the AC power cord when disconnecting it from an AC outlet. Grasp it by the plug.
- Do not put your fingers or objects into the unit.

LOCATION AND HANDLING

- The openings should not be blocked by placing the unit on a bed, sofa, carpet, rug, or other similar surface.
- Do not install the unit near or over a radiator or heat register.
- Do not install the unit in direct sunlight, near strong magnetic fields, or in a place subject to dust or strong vibration.
- Avoid a place with drastic temperature changes.
- Install the unit in a horizontal and stable position. Do not place anything directly on top or bottom of the unit. Depending on your external devices, noise or disturbance of the picture and/or sound may be generated if the unit is placed too close to them. In this case, please ensure enough space between the external devices and the unit.
- Depending on the environment, the temperature of this unit may increase slightly. This is not a malfunction.

DEW CONDENSATION WARNING

- Dew condensation may form inside the unit in the following conditions. If so, do not use this unit at least for a few hours until its inside gets dry.
  - The unit is moved from a cold place to a warm place.
  - Under conditions of high humidity.
  - After heating a cold room.

NOTE ABOUT RECYCLING

- This unit's packaging materials are recyclable and can be reused.
  Please dispose of any materials in accordance with your local recycling regulations.
- Batteries should never be thrown away or incinerated but disposed of in accordance with your local regulations concerning chemical wastes.

WHEN CARRYING THIS UNIT

- At least two people are required when carrying this unit.
- Make sure to hold the upper and bottom frames of the unit firmly as illustrated.



☑ Trademark Information

- HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.
- Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.
- Products that have earned ENERGY STAR® are designed to protect the environment through superior energy efficiency.
- DVD is a trademark of DVD Format/Logo Licensing Corporation.

☑ Supplied Accessories

remote control (RM-C-2152)

batteries (AA x 2)



Screw for attaching the stand x 4 (FPH34200)

- If you need to replace these accessories, please refer to the part No. with the illustrations and call our toll free customer support line found on the cover of this manual.

☑ Attaching the Stand

You must attach the stand to the unit to have it as a table top unit. Be sure the front and rear of the stand match the proper direction.

1 Spread a thick and soft cloth over a table as shown below.
Place the main unit face down onto it.
Make sure not to damage the screen.
At least two people are required at this step.

2 Align the 2 stand hooks with the two hooks under the bottom of the main unit (shown by arrow ①), then slide the stand in the direction as shown by arrow ②) until it stops and the 4 mounting holes are aligned.
Make sure not to put the AC power cord between the stand and the unit.

3 Drive screws in the 4 threaded holes at the bottom of the stand until they are tight.



To remove the stand from this unit

Unscrew the screws indicated by above "③". screw holes. After the screws are removed pull the stand up toward the rear of the unit. Be careful not to drop the stand when you remove it.

Note:

- *When attaching the stand, ensure that all screws are tightly fastened. If the stand is not properly attached, it could cause the unit to fall, resulting in injuries as well as damage to the unit.*
- *Make sure to use a table which can support the weight of this unit and is larger than this unit.*
- *Make sure the table is in a stable location.*

☑ Symbols Used in this Manual

The following is the description for the symbols used in this manual. Description refers to:

TV FUNCTIONS	DVD FUNCTIONS
TV : Analog TV operation	DVD : Playback of DVD-video
DTV : Digital TV operation	CD : Playback of audio CD
• If neither symbol appears under the function heading, operation is applicable to both.	• If neither symbol appears under the function heading, operation is applicable to both.

☑ Features

TV

- **DTV/TV/CATV**
  - You can use your remote control to select channels which are broadcast in digital format and conventional analog format. Also, cable subscribers can access their cable TV channels.
- **Information Display (DTV only)**
  - You can display the title, contents and other information of the current DTV program on the TV screen.
- **Autoscan**
  - This unit automatically scans and memorizes channels available in your area, eliminating difficult setup procedures.
- **Child Lock**
  - This feature allows you to block children's access to inappropriate programs.
- **Closed Caption Decoder**
  - Built-in closed caption decoder displays text for closed caption supported programs.
- **MTS/SAP Tuner**
  - Audio can be selected from the remote control.
- **Auto Shut Off Function**
  - If there is no signal input from the antenna terminal and no operation for 15 minutes, the unit will turn off automatically.
- **Sleep Timer**
  - This feature will automatically turn off the power of the unit at a specific time.
- **Choices for On-screen Language**
  - Select your on-screen language: English, Spanish or French.
- **Stereo Sound Function**
- **PLL Frequency Synthesized Tuning**
  - Provides free and easy channel selection and lets you tune directly to any channel using the number buttons on the remote control.
- **Various Adjustment for Picture and Sound**
  - Customizes image quality to suitable for your room and sets the sound as your preference.
- **HDMI Input**
  - When using HDMI1 input, you can enjoy this unit as a PC monitor if your PC has DVI output terminal.
- **Component Video Input**
- **S-video Input**
- **AV Input**
- **Digital Audio Output**
- **Analog Audio Output**

DVD

- **Dolby Digital Sound**
  - Enjoy Dolby Digital multi-channel surround sound when you connect the unit to your Dolby Digital decoder.
- **Still / Fast / Slow / Step Playback**
  - Various playback modes are available including still pictures, fast forward/reverse, slow motion and step frames.
- **DVD Menus in a Desired Language**
  - You can display DVD menus in a desired language, if available on a DVD-video.
- **Auto Power Off**
  - If there is no operation for 20 minutes, the unit will turn itself off automatically.
- **Parental Lock**
  - Block the viewing of DVD-video unsuitable for children.
- **Resume Playback**
  - Lets you resume playback from the point at which playback was stopped.
- **Bit Rate Indication**
- **DRC (dynamic range control)**
  - You can control the range of sound volume.

Accessing from **[MODE]** button

During playback

- **Subtitles in a Desired Language**
  - You can select a desired language for displaying subtitle, if that language is available on a DVD-video.
- **Selecting a Camera Angle**
  - You can select the desired camera angle, if a DVD contains sequences recorded from different angles.
- **Zoom**
  - Allows you to enlarge the size of picture image.
- **Black Level Adjustment**
- **Virtual Surround**
- **Search**
  - chapter search / title search / track search / time search
- **Marker**
  - The part on the disc designated by user can be called back.
- **Repeat**
  - chapter / title / track / all / A-B

Accessing from **[MODE]** button

In Stop mode

- **Program Playback for audio CD**
  - You can program the order of tracks to play them back in designated order.
- **Random Playback for audio CD**
  - This unit can shuffle the order of tracks to play them back in randomly.

Accessing from **[AUDIO]** button

During playback

- **Choices for Audio Language and Stereo Sound Function**
  - Select your desired languages or stereo sound function when different options are available on your disc.

☑ Contents

Precautions 2
Trademark Information....3

INTRODUCTION

Supplied Accessories....4
Attaching the Stand....4
Symbols Used in this Manual....4
Features....5
Control Panel 7
Terminals 7
Remote Control Function 8
Installing the Batteries....9

PREPARATION

Antenna Connection....10
Connection to Cable Receiver or Satellite Box 10
External Device Connection....11
Cable Management 14
Plug In the AC Power Cord 14

TV Functions

Initial Setup 15

WATCHING TV

Channel Selection....16
Volume Adjustment....16
Sleep Timer 16
Still Mode 17
Switching Each Input Mode 17
Switching Audio Mode....17
TV Screen Information....18
TV Screen Display Mode....19

OPTIONAL SETTING

Main Menu....20
Autoscan....20
Channel List....21
Manual Register....21
Antenna Confirmation 22
Language Selection 22
Picture Adjustment 23
Sound Adjustment....24
Closed Caption....25
Child Lock....28
PC Settings....32
Energy Saving Mode 33
Location 33
Current Software Info 34

DVD Functions

OPERATING DVD

Playable Media....35
Unplayable Media....35
Playback 36
Disc Menu....36
Resume Playback 36
Paused and Step-by-step Playback....36
Fast Forward / Fast Reverse 37
Slow Forward / Slow Reverse....37
Zoom 37
Search Functions....38
Repeat Playback....39
Repeat A-B Playback 40
Random Playback....40
Programmed Playback....40
On-screen Display....41
Special Settings 41

DVD SETTING

DVD Language Setting....44
DVD Audio Setting....45
Parental Setting....46
Others....47
Reset to the Default Setting 48
Language Code List 48

TROUBLESHOOTING

FAQ....49
Troubleshooting Guide 50

INFORMATION

Glossary....52
Maintenance....52
Cable Channel Designations 53
General Specifications....53
Electrical Specification 53
Other Specifications....53

Limited Warranty....Back Cover

☑ Control Panel



1. ⏻ (power) (p. 15)
   Press to turn the unit on and off.
2. ▶ (play) (p. 36)
   Press to begin the disc playback.
3. ■ (stop) (p. 36)
   Press to stop the disc playback.
4. ▲ (eject) (p. 36)
   Press to eject the disc.
5. **CH −/ +** (p. 16 / p. 17)
   Press to select channels or move up (**+**) / down (**−**) through the main menu items.
6. **SETUP** (p. 15 / p. 44)
   Press to display the main menu.
7. **VOL −/ +** (p. 16)
   Press to adjust the volume or move right (**+**) / left (**−**) through the main menu items.
8. **infrared sensor window**
   Receives infrared rays transmitted from the remote control.
9. **POWER ON indicator**
   Lights up blue when power is on.
10. **STAND BY indicator**
    Lights up red when power is off.
11. **DVD indicator**
    Lights up orange when the disc is inserted.

☑ Terminals



[Side Panel]

12. **disc loading slot** (p. 36)
    Insert the disc with the label side facing forward.
13. **S-video input jack** (p. 12)
    S-video cable connection from an external device.
14. **video input jack** (p. 13)
    RCA video cable connection from an external device.
15. **audio input jack** (p. 12 / p. 13)
    RCA audio cable connection from an external device.
16. **HDMI 2 input jack** (p. 10 / p. 11)
    HDMI connection from HDMI device.

[Rear Panel]

17. **AC power cord** (p. 14)
    Connect to a standard AC outlet to supply power to this unit.
18. **cable management** (p. 14)
    Use this holder to bundle the cables.
19. **component video and audio input jack** (p. 10 / p. 12)
    RCA component video cable and RCA audio cable connection from an external device.
20. **audio output jack** (p. 13)
    RCA audio cable connection for an external device.
21. **audio input jack for HDMI 1** (p. 11 / p. 14)
    RCA audio cable connection from a DVI device.
    When you connect your PC that has a DVI terminal, use a stereo mini plug-RCA conversion cable as well. (For HDMI 1 input jack only)
22. **digital audio output jack** (p. 13)
    Coaxial digital cable connection for a decoder or an audio receiver.
23. **antenna input jack** (p. 10)
    RF coaxial cable connection for your antenna or cable/ TV signal.
24. **HDMI 1 input jack** (p. 10 / p. 11 / p. 14)
    HDMI connection for HDMI or DVI device.
    When you connect your PC that has a DVI terminal, you can enjoy this unit as a PC monitor.

Note:

*** service terminal (service use only)**

- *User should not connect any devices to the service terminal such as digital camera, keyboard, mouse, etc. (because these will not work).*

☑ Remote Control Function



1. **MUTE** (p. 16)
   Press to turn the sound on and off.
2. **Number buttons** (p. 16)
   • Press to select channels.
   • Press to select chapter, title (DVD), or track (CD) directly.
   – (hyphen)
   • Press to shift the subchannel from the main channel.
   +10 button
   • Press to select 10 or higher number of chapters.
3. **SETUP** (p. 15 / p. 44)
   Press to display the main menu.
4. **◄ / ► / ▲ / ▼** (p. 15)
   Press to move left / right / up / down through the items.
5. **ENTER** (p. 15)
   Press to decide the command of setting when the main menu is displayed.
6. **INFO** (p. 18 / p. 41)
   Digital mode (DTV)
   • Press to display the channel information, signal type and TV setting.
   Analog mode (TV)
   • Press to display the channel number, signal type and TV setting.
   External input mode
   • Press to display the external input mode, signal type and TV setting.
   DVD mode
   • Press to display the current status.
7. **CHANNEL –/ +** (p. 16 / p. 17)
   Press to select channels and the external input mode.
8. **REV ◄◄ / FWD ►►** (p. 37)
   Press to begin slow forward or slow reverse playback during the pause mode (DVD) and search forward or backward through the disc.
9. **SKIP |◄◄ / ►►|** (p. 38)
   Press to skip forward or backward chapters, titles (DVD) or tracks (CD).

10. EJECT ⏏ (p. 36)
Press to eject the disc.

11. DISC MENU (p. 36)
Press to display the menu on the disc.

12. TITLE (p. 36)
Press to display the title menu (DVD).

13. INPUT SELECT (p. 17)
Press to access connected external devices like a BD/DVD recorder.

14. POWER (p. 15)
Press to turn the unit on and off.

15. AUDIO (p. 17 / p. 42)
Digital mode (DTV)
• Press to select the audio language.
Analog mode (TV)
• Press to select the audio mode.
DVD mode
• Press to select the audio language (DVD), or sound mode (CD).

16. SLEEP (p. 16)
Press to activate the sleep timer.

17. CH RETURN (p. 16)
Press to return to previously viewed channel.

18. SCREEN MODE (p. 19)
Press to select aspect ratio available for the TV screen.

19. BACK (p. 18)
Press to return to the previous menu operation.

20. VOLUME –/ + (p. 16)
Press to adjust the volume.

21. PLAY ▶ (p. 36)
Press to begin the disc playback.

22. STOP ■ (p. 36)
Press to stop the disc playback.

23. PAUSE ❚❚ (p. 17)
TV mode
• Press to pause screen image.
DVD mode
• Press to pause the disc playback.

24. CLEAR (p. 39)
• Press to clear the numbers entered incorrectly.
• Press to cancel the point A for A-B repeat.
• Press to remove the track number in program input (CD).

25. MODE (p. 5)
• Press to arrange the playing order or playback randomly (CD).
• Press to set the black level (DVD) and the virtual surround on or off.
• Press to change the camera angle to see the sequence being played back from different angle (DVD).
• Press to search chapter, title (DVD), track (CD) or time.
• Press to set the marker.
• Press to repeat playback chapter, title (DVD), track, disc (CD) repeatedly or between designated point A and B.
• Press to magnify the part of picture (2x and 4x : DVD).
• Press to select the subtitles on the disc (DVD).

☑ Installing the Batteries

Install the batteries (AA x 2) matching the polarity indicated inside battery compartment of the remote control.



Battery Precautions:
- *Be sure to follow the correct polarity as indicated in the battery compartment. Reversed batteries may cause damage to the device.*
- *Do not mix different types of batteries together (e.g., Alkaline and Carbon-Zinc, or rechargeable batteries like ni-cad, ni-mh, etc) or old batteries with fresh ones.*
- *If the device is not to be used for a long period of time, remove the batteries to prevent damage or injury from possible battery leakage.*
- *Do not try to recharge batteries; they can overheat and rupture.*

No supplied cables are used in this connection:

Please purchase the necessary cables at your local store.
High Speed HDMI cable (also known as HDMI category 2 cable) is recommended for the better compatibility.

Before you connect...
Be sure your antenna or other device is connected properly before plugging in the AC power cord.

☑ Antenna Connection

Connect the RF coaxial cable on your home outlet to the antenna input jack of this unit.



* Once connections are completed, turn on the unit and begin initial setup. Channel scanning is necessary for the unit to memorize all available channels in your area. (Refer to "Initial Setup" on page 15.)

Note:

- *If you have any question about the DTV's antenna, visit www.antennaweb.org for further information.*
- *Depending on your antenna system, you may need different types of combiners (mixers) or separators (splitters). Contact your local electronics store for these items.*
- *For your safety and to avoid damage to this unit, please unplug the RF coaxial cable from the antenna input jack before moving the unit.*
- *If you use an antenna to receive analog TV, it should also work for DTV reception. Outdoor or attic antennas will be more effective than settop versions.*
- *To switch your reception source easily between antenna and cable, install an antenna selector.*
- *If you connect to the cable system directly, contact the CATV installer.*

☑ Connection to Cable Receiver or Satellite Box

Use an HDMI or an RCA component video cable to connect the HDMI or the component video input jack of the unit to the HDMI or the component video output jack of the cable receiver / satellite box.
If you connect to the unit's component Video Input jack, connect RCA audio cables to the Audio L/R jacks below the Component Video connector.



* You can also connect this unit to the cable receiver or satellite box other than the HDMI or the component video output jack because they might have different output jacks.
* Required cables and connecting methods of the cable receiver / satellite box, or the availability channel for the clear QAM may differ depending on the cable / satellite provider. For more information, please contact your cable / satellite provider.

No supplied cables are used in this connection:

Please purchase the necessary cables at your local store.
High Speed HDMI cable (also known as HDMI category 2 cable) is recommended for the better compatibility.

☑ External Device Connection

[HDMI Connection]

HDMI connection offers the highest picture quality. HDMI (High-Definition Multimedia Interface) transports high definition video and multi-channel digital audio through a single cable.
HDMI CEC (Consumer Electronics Control) allows the TV to connect and control multiple HDMI CEC enabled devices with a single remote. CEC (Consumer Electronics Control) is an optional protocol used in HDMI.

- HDMI CEC on this TV is compliant with "High-Definition Multimedia Interface Specification".
- The TV does not support HDMI CEC functions that are not listed below.
- The TV does not guarantee to support use of all HDMI CEC enabled devices.
- Devices that are not enabled to HDMI CEC cannot be controlled with this TV.

■ Control the TV using the HDMI CEC enabled device
- Turn the TV on and switch to the video source of the operating device.
- Switch to the video source of the operating device.

■ Control the HDMI CEC enabled device using the TV
- Turn off the operating device by pressing the power button for three seconds or more, and turning off the TV.

* Some device may not support this function. For more details refer to the device's manual.

■ Send status of the TV to the HDMI CEC enabled device
- When switching the TV's external input or channel.
- When switching the TV's menu language.

* Information regarding behaviour of the device when status is received, refer to the external device's manual.

e.g.)



Note:

- *This unit accepts 480i / 480p / 720p / 1080i video signals, and 32kHz / 44.1kHz / 48kHz audio signals.*
- *This unit accepts only 2 channel audio signal (LPCM).*
- *You need to select "PCM" for the digital audio output of the device you connected or check the HDMI audio setting. There may be no audio output if you select "Bitstream", etc.*
- *This unit only accepts signals in compliance with EIA861.*

[HDMI-DVI Connection]

Use an HDMI-DVI conversion cable to connect the unit to external video devices equipped with DVI output jack.

e.g.)



Note:

- *This unit accepts 480i / 480p / 720p / 1080i video signals.*
- *HDMI-DVI connection requires separate RCA audio connections as well.*
- *Audio signals are converted from digital to analog for this connection.*
- *DVI does not display 480i image that is not in compliance with EIA/CEA-861/861B.*

No supplied cables are used in this connection:

Please purchase the necessary cables at your local store.

[Component Video Connection]

RCA component video connection offers better picture quality for video devices connected to the unit.
If you connect to the unit's component Video Input jack, connect RCA audio cables to the Audio L/R jacks below the Component Video connector.

e.g.)



Note:

- *This unit accepts 480i / 480p / 720p / 1080i video signals.*

[S-video Connection]

S-video connection offers good picture quality for video devices connected to the unit.
If you connect to the unit's S-Video Input jack, connect RCA audio cables to the Audio L/R jacks below the Video connector.

e.g.)



Note:

- *If you connect to the S-video input jack and the video input jack at the same time, the S-video connection will have priority.*

No supplied cables are used in this connection:

Please purchase the necessary cables at your local store.

[Video Connection]

RCA video connection offers standard picture quality for video devices connected to the unit.
If you connect to the unit's Video Input jack, connect RCA audio cables to the Audio L/R jacks below the Video connector.
When the audio jack of the video device is monaural, connect an RCA audio cable to the audio L input jack.

e.g.)



Note:

- *If you connect to the S-video input jack and the video input jack at the same time, the S-video connection will have priority.*

[Audio Output Connection]

✱ **Digital** (for digital broadcasting only)
If you connect this unit to an external digital audio device, you can enjoy multi-channel audio like 5.1ch digital broadcasting sound.
Use a digital audio coaxial cable to connect the unit to external digital audio devices.

✱ **Analog** (for both analog and digital broadcasting)
If you connect this unit to an external analog audio device, you can enjoy stereo (2-channel) audio.
Use an RCA audio cable to connect the unit to external analog audio devices.

e.g.)



No supplied cables are used in this connection:

Please purchase the necessary cables at your local store.

[PC Connection]

This unit can be connected to your PC that has a DVI terminal. Use an HDMI-DVI conversion cable for this connection and it requires stereo mini plug-RCA conversion cable as well.
If you connect this unit to your PC, you can use this unit as a PC monitor.

e.g.)


stereo mini plug-RCA conversion cable
To HDMI1 input jack only
rear of this unit
HDMI-DVI conversion cable
DVI OUT
personal computer
HDMI-DVI conversion cable should be with ferrite core.

The following signals can be displayed:

Format	Resolution	Refresh rate
VGA	640 x 480	60Hz
SVGA	800 x 600	60Hz
XGA	1,024 x 768	60Hz

Format	Resolution	Refresh rate
WXGA	1,280 x 768	60Hz
	1,360 x 768	60Hz

Other formats or non-standard signals will not be displayed correctly.

Note:

- *Please purchase the HDMI-DVI conversion cable that has a ferrite core.*
- *The following operations may reduce noise.*
  - *Attach a ferrite core to the AC power cord of your PC.*
  - *Unplug the AC power cord and use the built-in battery of your PC.*

☑ Cable Management

Keep the cables through this holder to avoid tangle them.



☑ Plug In the AC Power Cord

Make sure that the AC power cord must be plugged to an AC outlet after all the necessary connections are completed.



Caution:

- *Do not connect the AC power cord to a power supply outside the indicated voltage of this unit (AC 120V).*
  Connecting the AC power cord to a power supply outside of this range may result in fire or electrical shocks.

Note:

- *Each time you plugged in the AC power cord, any operations will not be performed for a few seconds. This is not a malfunction.*

These operations are accessible by remote control. Some may also be accessible by controls on the main unit.

TV Functions

☑ Initial Setup

This section will guide you through the unit's initial setting which includes selecting a language for your on-screen menu and autoscan, which automatically scans and memorizes viewable channels.

Before you begin:
Make sure the unit is connected to antenna or cable.

1 After making all the necessary connections, press **[POWER]** to turn on the unit.

POWER

- This operation may take a few moments.

2 Use **[Cursor ▲/▼]** to select the on-screen language from the choices on the right side of the TV screen. (English / Español / Français)

- "Initial Setup" menu on step 3 will be displayed in the selected language after you press **[ENTER]**.

3 Use **[Cursor ▲/▼]** to select "Antenna" for TV channels or "Cable" for CATV channels, then press **[ENTER]**.



- "Autoscan" will begin.



4 Use **[Cursor ◄/►]** to select the desired location setting, then press **[ENTER]**.





- Select "Retail", the unit will be set up with predefined setting for retail displays. In this setting, the power consumption may possibly exceed the limited requirement of the ENERGY STAR® qualification.
- Select "Home", the unit is set to maximize the energy efficiency for home setting and it can be adjusted through a choice of picture and sound quality according to your preference.
- When the initial setup is completed, the lowest memorized channel with the confirmation message of the location setting will be displayed on the TV screen.

Note:

- *If you connect the cable system directly, contact the CATV installer.*
- *If you press **[POWER]** or **[SETUP]** during autoscan, this setting will be canceled.*
- *The initial autoscan function can be executed for either "Antenna" or "Cable" only once. When you change the connection (Antenna / Cable), set autoscan again. (Refer to page 20.)*
- *If there is no signal input from the antenna terminal and no operation for several seconds after you turn on the unit, "Helpful Hints" appears. Follow the instructions listed on the TV screen.*


Initial Setup
No channel s registered
Try Autoscan again?
Ver fy that you have a cable connected o he "ANT IN" jack
on he back of the TV the channel nstallation p ocess
searches this connection If you are using a cable or satel ite
box please conf rm the input which you have connec ed the
box and press the "INPUT SELECT" key on the remote con rol to
se ect he appropr ate source input
Retry
Later
Select
Enter
SETUP
Skip

- *You must set "Home" in step 4. Otherwise, the settings of picture and sound quality you adjusted will not be memorized after you turn off the unit.*

After an initial setup is completed...

- If you want to scan the channels automatically again, refer to "Autoscan" on page 20.
- You can add the desired channels unmemorized by "Autoscan". Refer to "Manual Register" on page 21.
- If you want to change to another language, refer to "Language Selection" on page 22.
- If you want to change the Location setting, refer to "Location" on page 33.

☑ Channel Selection

Select channels by using [CHANNEL −/ +] or [the Number buttons].

- To select the memorized channels, use **[CHANNEL −/ +]** or **[the Number buttons]**.
- To select the non-memorized channels, use **[the Number buttons]**.

To Use [the Number buttons]

TV

- When selecting channel 11

DTV

- When selecting digital channel 11-1
  Be sure to press **[−]** before entering the subchannel number.

- Press **[CH RETURN]** to return to the previously channel.

About digital TV broadcasting:

With its high definition broadcast, digital broadcasting far surpasses analog broadcasting in both its picture and sound quality. Not all digital TV broadcasts are high definition (HD). To confirm whether your watching TV program is in HD, refer to the program guide, contact your cable / satellite provider or local TV stations.



⇔ can be changed by using **[CHANNEL −/ +]**.

What is the subchannel?

By using high compression technology, digital broadcasting offers a service that enables multiple signals to send simultaneously.
Therefore, you can select more than one program per main channel since digital broadcasting technology distinguishes between multiple channels broadcast by a single network.

Note:

- *"No Signal" will appear on the TV screen after the subchannel broadcast is over.*
- *"Audio only program" message will appear on the TV screen, when you receive only sound signal.*

☑ Volume Adjustment

This section describes how to adjust the volume. The mute function, which turns the sound off and on, is also described.

Use **[VOLUME −/ +]** to adjust the audio volume.

The volume bar will be displayed at the bottom of the TV screen when adjusting the volume.

- The volume bar will automatically disappear in a few seconds.

Press **[MUTE]** to turn off and on the sound.

"Mute" is displayed on the TV screen for a few seconds.

Press **[MUTE]** again or **[VOLUME −/ +]** to recover the original volume.

☑ Sleep Timer

The sleep timer can be set to automatically turn off the unit after an incremental period of time.

1 Press **[SLEEP]** to set the sleep timer.



Sleep timer display appears on the TV screen.

2 Press **[SLEEP]** repeatedly to change the amount of time until shut off.



You can set your unit to turn off after a set period of time (from 30 to 120 minutes).

- Each press of **[SLEEP]** will increase the time by 30 minutes.
- After setup, the sleep timer display can be called up for checking by pressing **[SLEEP]**.

To cancel the sleep timer

Press **[SLEEP]** repeatedly until "Sleep Off" is displayed on the TV screen.

Note:

- *The sleep timer display will automatically disappear in a few seconds.*
- *When you disconnect the unit from the AC outlet or when a power failure occurs, the sleep timer setting will be canceled.*

☑ Still Mode

You can pause the image shown on the TV screen.

Press **[PAUSE ❚❚]** to pause the image shown on the TV screen.

- The sound output will not be paused.
- If no signal is detected or protected signal is received during still mode, the image remains paused and the sound output will be muted.
- The still function will be released after 5 minutes.

To cancel still mode, press any button except **[POWER]**.

☑ Switching Each Input Mode

You can easily switch with the remote control to the DTV (ATSC) and TV (NTSC) or to access external devices when they are connected to the unit.

Press **[INPUT SELECT]** or **[CHANNEL +]** repeatedly to cycle through the input modes.



- Pressing **[CHANNEL −]** reverses the direction of the input modes.

☑ Switching Audio Mode

This section describes how to switch the audio in the analog mode and how to switch the audio language in the digital mode.

TV

Press **[AUDIO]** to display the currently selected audio mode. While receiving an MTS broadcast, press repeatedly to cycle through the available audio channel.

When all audio are available

When stereo and monaural audio are available

When SAP and monaural audio are available

When only monaural audio is available

(cannot be switched)

STEREO : Outputs stereo-audio
SAP : Outputs second audio program
MONO : Outputs mono-audio

DTV

1 Press **[AUDIO]** to display the currently selected language and the number of available languages.

2 Press **[AUDIO]** repeatedly to cycle through the available audio languages.

- Available languages differ depending on the broadcast. "Other" is displayed when the audio language cannot be acquired, or the acquired languages are other than English, Spanish or French.

Note:

- ***[AUDIO]*** *does not control external audio devices.*
- *The information display will automatically disappear in a few seconds.*

☑ TV Screen Information

You can display the currently selected channel or other information such as the audio mode on the TV screen.

TV

In the analog mode, the current channel number and the audio mode are displayed.

Press **[INFO]**.



- The current channel number, audio mode, type of resolutions for video signal, TV aspect ratio, CC and TV program rating are displayed on the top-right corner of the TV screen.
- To clear the display, press **[INFO]** again. You can also press **[BACK]**.

DTV

In the digital mode, the detailed broadcasting information for the current channel such as program title, program guides are displayed.

Press **[INFO]** to display the details of the currently selected program.

Broadcasting information

The following information is displayed.



1 program title
2 program guide
(The program guide added to broadcasting information is displayed to a maximum of 4 lines.)
3 broadcast station
4 channel number
5 audio language
(Refer to "Switching Audio Mode" on page 17.)
6 effective scanning lines and scan mode
7 digital TV format
8 program aspect ratio
9 CC (not available if closed caption is set to "Off")
10 child lock rating

Note:

- *When the program guide consists of more than 4 lines, use **[Cursor ▲/▼]** to scroll.*
- *"No description provided." is displayed when the program guide is not provided.*
- *While the program guide is displayed, the closed caption function is interrupted.*
- *In external input mode, the following screen is displayed; e.g.) When an external device is connected to VIDEO input jack.*

- *The information display will automatically disappear in 1 minute.*

☑ TV Screen Display Mode

4 types of display modes can be selected when the broadcasting station is sending 4:3 or 16:9 video signal. And 3 types of display modes can be selected for PC input signal.

Press **[SCREEN MODE]** repeatedly to switch the TV aspect ratio.

For 4:3 video signal



Sidebar
Display a 4:3 picture at its original size. Sidebars appear on both edges of the screen.

Full
Display a 4:3 picture at a 16:9 size; the picture is stretched horizontally to fill the screen.

Cinema
Display a 4:3 picture at a 16:9 size; the picture is stretched horizontally and vertically to fill the screen. This crops out the top and bottom of the picture.

Wide
Display the picture with its center at the original size and the edges stretched horizontally to fill the screen.

For 16:9 video signal



Full
Display a 16:9 picture at its original size.

Zoom
Display a 16:9 picture at its maximum size without changing its horizontal and vertical ratio.

Cinema
Display a vertically stretched picture.

Expand
Display a horizontally stretched picture.

For PC input signal through HDMI1 input mode



Normal
Display a proportionately stretched picture. Sidebars appear on both edges of the screen.

Full
Display a picture that is stretched out of proportion to fill the screen.

Dot By Dot
Display a picture in its original size.

☑ Main Menu

This section describes the overview of the main menu displayed when you press [SETUP]. For more details, see the reference page for each item. The main menu consists of the function setting items below.

Press **[SETUP]**.

PICTURE
You can adjust the picture quality.
(Refer to "Picture Adjustment" on page 23.)

SOUND
You can adjust the sound quality.
(Refer to "Sound Adjustment" on page 24.)

CHANNEL
- You can automatically scan the viewable channels. (Refer to "Autoscan" on page 20.)
- You can skip the undesired channels when selecting the channels using **[CHANNEL −/ +]**. (Refer to "Channel List" on page 21.)
- You can add the channels that were not scanned by the autoscan. (Refer to "Manual Register" on page 21.)

DETAIL
- You can change the display format for closed caption, which displays the dialogue of a TV program or other information across the TV screen. (Refer to "Closed Caption" on page 25.)
- You can set the viewing limitations. (Refer to "Child Lock" on page 28.)
- You can adjust the position, stability and clarity of the PC screen. (Refer to "PC Settings" on page 32.)
- You can select the energy saving mode. (Refer to "Energy Saving Mode" on page 33.)
- When you adjust the desired "PICTURE" and "SOUND" mode, you must switch the setting from "Retail" to "Home". (Refer to "Location" on page 33.)
- You can confirm the version of the software currently used in this unit. (Refer to "Current Software Info" on page 34.)

LANGUAGE
You can change the language (English, Spanish, French) displayed on the main menu.
(Refer to "Language Selection" on page 22.)

DVD
You can customize some functions for the disc playback. Make sure the player is in stop mode.
(Refer to "DVD SETTING" section on page 44.)

☑ Autoscan

If you switch wires (e.g., between antenna and CATV) or if you move the unit to a different area after the initial setting, or if you restore the DTV channel you deleted, you will need to perform autoscan.

Before you begin: **Make sure the unit is connected to antenna or cable.**

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "CHANNEL" , then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Autoscan", then press **[ENTER]**.



Use **[Cursor ▲/▼]** to select an appropriate option, then press **[ENTER]**.



- When aerial antenna is connected, select "Antenna".
- When connected to CATV, select "Cable".
- "Autoscan" will begin.



- When the scanning and memorizing are completed, the lowest memorized channel will be displayed.

Note:
- *After setting "Autoscan", using **[CHANNEL −/ +]** on the remote control skips unavailable programs automatically.*
- *If you connect the cable system directly, contact the CATV installer.*
- *If you press **[POWER]** or **[SETUP]** during autoscan, the setting will be canceled.*
- *Even if "Autoscan" is completed, the channel setting will be lost if the AC power cord is unplugged before turning off the unit by pressing **[POWER]**.*
- *The PIN Code will be required once you set a PIN Code in the "Child Lock" (Refer to page 28).*
- *If you want to change your PIN Code, follow the instruction of "New Password" (Refer to page 31).*

☑ Channel List

The channels selected here can be skipped when selecting the channels using [CHANNEL −/ +].
Those channels can still be selected with [the Number buttons].

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "CHANNEL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Channel List", then press **[ENTER]**.



4 Use **[Cursor ▲/▼]** to select the channel you want to remove, then press **[ENTER]**.

- The channel display for the removed channel darkens. You will not be able to select the channel again using **[CHANNEL − / +]**.
- To reactivate a removed channel, use **[Cursor ▲/▼]** and press **[ENTER]**. The registered channels are highlighted.
- When you remove a main channel, its subchannels are removed as well.

Note:
- *The channel with the "DTV" indicated on the display is ATSC. Otherwise the channel is NTSC.*

5 Press **[SETUP]** to exit.

☑ Manual Register

This function lets you add the channels that were not added by the autoscan due to the receptible condition at the initial setting.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "CHANNEL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Manual Register", then press **[ENTER]**.



4 Use **[the Number buttons]** to enter the number of the channel you want to add, then press **[ENTER]**.



5 Press **[SETUP]** to exit.

Note:
- *If setup completes successfully, "Added to the channel list" is displayed.*
- *If external input is used, it is not possible to register the channel and "Unavailable" will be displayed on the TV screen.*
- *By using **[CHANNEL − / +]**, you can select the memorized channels only.*

☑ Antenna Confirmation

DTV

This function lets you check the digital signal strength of each channel.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "CHANNEL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Antenna", then press **[ENTER]**.



4 Use **[the Number buttons]** or **[CHANNEL — / +]** to select the channel for which you want to check the digital signal strength.



11-1



- If the channel is set to analog channel or external input, you cannot confirm the antenna condition.

Video



5 Press **[SETUP]** to exit.

☑ Language Selection

You can choose English, Spanish, or French as your on-screen language.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "LANGUAGE", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "English", "Español" or "Français", then press **[ENTER]**.

4 Press **[SETUP]** to exit.

Note:

- *If you need the English menus instead of the Spanish or French menus, press **[SETUP]**. Use **[Cursor ▲/▼]** to select "IDIOMA" or "LANGUE", then press **[ENTER]**.*
  *Use **[Cursor ▲/▼]** to select "English", then press **[ENTER]**.*
  *Press **[SETUP]** to exit the main menu.*

☑ Picture Adjustment

You can adjust brightness, contrast, color, tint, sharpness and color temperature.

Before you begin: **You must set "Home" in "Location" (Refer to page 33). Otherwise, the settings you adjusted will not be memorized after you turn off the unit.**

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "PICTURE", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select the item you want to adjust, then press **[ENTER]**.



4 Adjust the picture quality.

Picture Mode

Use **[Cursor ▲/▼]** to select the desired setting, then press **[ENTER]**.
("Personal", "Standard", "Sports", "Movie" and "Game")



Brightness, Contrast, Color, Tint, Sharpness, Color Temperature

Use **[Cursor ▲/▼]** to select the desired setting, then use **[Cursor ◀/▶]** to adjust.



	Cursor ◀	Cursor ▶
Brightness	to decrease brightness	to increase brightness
Contrast	to decrease contrast	to increase contrast
Color	to decrease color intensity	to increase color intensity
Tint	to add red	to add green
Sharpness	to soften	to sharpen
Color Temperature	to add warm colors	to add cool colors

5 Press **[SETUP]** to exit.

Note:

- *To cancel picture adjustment, press **[SETUP]**.*
- *Only the "Personal" setting can be adjusted.*

☑ Sound Adjustment

You can adjust the sound mode, equalizer and some other sound functions.

Before you begin: **You must set "Home" in "Location" (Refer to page 33). Otherwise, the settings you adjusted will not be memorized after you turn off the unit.**

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "SOUND", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select the sound type you want to adjust, then press **[ENTER]**.



4 Adjust the following items.

Sound Mode

Use **[Cursor ▲/▼]** to select the desired setting, then press **[ENTER]**.
("Personal", "Standard", "Movie", "Music" and "News")



Equalizer

Adjust tonal quality for each frequencies.
Use **[Cursor ◄/►]** to select the specific frequency and use **[Cursor ▲/▼]** to adjust the level, then press **[ENTER]**.



Auto Volume Leveling

This function keeps a constant loudness differential between the TV commercials and the programs.

Use **[Cursor ▲/▼]** to select the desired option, then press **[ENTER]**.



On	Select if you want to reduce volume differences between the TV commercials and the programs.
Off	Select if you want to remove the auto volume leveling.

TV Speakers

Select the audio output from the unit's speakers, or not. If your amplifier compatible with the CEC function is connected to this unit using an HDMI cable, some part of the sound operations such as volume up can access synchronized by using this unit's remote control.

Use **[Cursor ▲/▼]** to select the desired option, then press **[ENTER]**.

or
ENTER
TV Speakers
"On":
Sound will be output from heTV speakers
"Off":
Sound will not be output from he TV speakers
"Ext Amp":
Operation s possib e by connecting to the HDMI CEC compa ible amp with a HDMI cable For deta ls look in the user manual
On
Off
Ext Amp

On	The sound will be output from the unit's speakers.
Off	The sound will not be output from the unit's speakers.
Ext. Amp	This function allows you to control audio output from CEC-compatible devices with the unit's remote control.

5 Press **[SETUP]** to exit.

Note:

- *To cancel sound adjustment, press **[SETUP]**.*
- *We do not guarantee 100% interoperability with other brands of CEC compliant devices.*

☑ Closed Caption

You can view closed captioning (CC) for TV programs, movies and news. Closed caption refers to text of dialogue or descriptions displayed on-screen.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Closed Caption", then press **[ENTER]**.



See the following description for setting each item.



A··· "A. Caption Service" ⇨ page 25

B··· "B. Digital Caption Service" ⇨ page 26

C··· "C. Caption Style" ⇨ page 26

A. Caption Service

4 Use **[Cursor ▲/▼]** to select "Caption Service", then press **[ENTER]**.



5 Use **[Cursor ▲/▼]** to select the desired closed caption, then press **[ENTER]**.



Caption mode

CC1 and Text1;

are the primary caption and text services.
The captioning or text is displayed in the same language as the program's dialogue
(up to 4 lines of script on the TV screen, where it does not obstruct relevant parts of the picture).

CC3 and Text3;

serve as the preferred data channels.
The captioning or text is often a secondary language.

CC2, CC4, Text2 and Text4;

are rarely available and broadcasters use them only in special conditions, such as when "CC1" and "CC3" or "Text1" and "Text3" are not available.

- There are 3 display modes according to programs:

Paint-on mode:
Displays input characters on the TV screen immediately.

Pop-on mode:
Once characters are stored in memory, they are displayed all at once.

Roll-up mode:
Displays the characters continuously by scrolling (max. 4 lines).

6 Press **[SETUP]** to exit.

B. Digital Caption Service

DTV

In addition to the basic closed caption described on page 25, DTV has its own closed caption called digital caption service. Use this menu to change the settings for digital caption service.

4 Use **[Cursor ▲/▼]** to select "Digital Caption Service", then press **[ENTER]**.

5 Use **[Cursor ▲/▼]** to select the desired digital caption service, then press **[ENTER]**.



Off	Select if you do not want digital caption service. This is the default.
Service 1~6	Select one of these before changing any other item in "Closed Caption" menu. Choose "Service1" under normal circumstances.

6 Press **[SETUP]** to exit.

Note:

- *"Digital Caption Service" that you can switch differs depending on the broadcast description.*

C. Caption Style

DTV

You can change the caption style such as font, color or size, etc.

4 Use **[Cursor ▲/▼]** to select "Caption Style", then press **[ENTER]**.



5 Use **[Cursor ▲/▼]** to select "User Setting", then press **[ENTER]**.

6 Use **[Cursor ▲/▼]** to select "On", then press **[ENTER]**.



7 Use **[Cursor ▲/▼]** to select an item, then press **[ENTER]**. Then use **[Cursor ▲/▼]** to select the desired setting and press **[ENTER]**.



- The setting description for each item is shown on the next page.
- Review your setting choice made on the next page by looking in the upper right corner of the displayed setting box (not all selections show the differences selected).

Font Style
Closed Captioning font style can be changed as below.



Font Size
Font size of the displayed caption can be switched as below.



Font Color
Font color of the displayed caption can be switched as below.



Font Opacity
Font opacity of the displayed caption can be switched as below.



Background Color
Background color of the displayed caption can be switched as below.



Background Opacity
Background opacity of the displayed caption can be switched as below.



Edge Color
Edge color of the displayed caption can be switched as below.



Edge Type
Edge type of the displayed caption can be switched as below.

8 Press **[SETUP]** to exit.

SETUP

Note:

- *To show the closed caption on your TV screen, broadcast signal must contain the closed caption data.*
- *Not all TV programs and commercials have the closed caption or all types of the closed caption.*
- *Captions and texts may not match the TV voice exactly.*
- *Changing channels may delay the closed caption for a few seconds.*
- *Adjusting or muting the volume may delay the closed caption for a few seconds.*
- *Abbreviations, symbols and other grammatical shortcuts may be used in order to keep pace with the on-screen action. This is not a malfunction.*
- *The caption or text characters will not be displayed while the main menu or functions display is shown.*
- *If a black box appears on the TV screen, this means that the closed caption is set to the text mode. To clear the box, select "CC1", "CC2", "CC3", "CC4" or "Off".*
- *If the unit receives poor quality television signals, the captions may contain errors, or there might be no captions at all. Some possible causes of poor quality signals are:*
  - Automobile ignition noise
  - Electric motor noise
  - Weak signal reception
  - Multiplex signal reception (ghosts or screen flutter)
- *The unit retains the closed caption setting if the power fails.*
- *Closed caption will not be displayed when you are using an HDMI connection.*
- *When the unit receives special effects playback signal (i.e., Search, Slow and Still) from a VCR's video output channel (CH3 or CH4), the unit may not display the correct caption or text.*

☑ Child Lock

Child lock reads the ratings for programs, then denies access to the programs which exceed the rating level you set. With this function, you can block certain programs inappropriate for children and any channels or external input modes can be invisible.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Child Lock", then press **[ENTER]**.

4 Use **[the Number buttons]** to enter the 4-digit numbers for your PIN Code.



- When you have not set up your PIN Code, enter 0000.
- When the PIN Code is correct, "Child Lock" menu is displayed.

See the following description for setting each item.

A···"A. Channel Lock" ⇨ page 29

B···"B. MPAA Rating" ⇨ page 29

C···"C. TV Rating" ⇨ page 30

D···"D. New Password" ⇨ page 31

Note:

- *When you select a rating and set it to "Block", the higher ratings will be blocked automatically. The lower ratings will be available for viewing.*
- *When you set the highest rating to "View", all ratings turn to "View" automatically.*
- *To block any inappropriate programs, set your limits in "MPAA Rating", "TV Rating" and "Downloadable Rating".*
- *The child lock setting will be retained after a power failure (except the access code reverts to 0000).*
- *If the rating is blocked, 🔒 will appear.*
- *"Downloadable Rating" will be available when the unit receives a digital broadcast using the new rating system.*
- *If the broadcasting signal does not have the Downloadable Rating information, "Downloadable Rating is currently not available." will appear. This message will also appear when you try to access "Downloadable Rating" after you have cleared the Downloadable Rating information, and the new information has not been downloaded since.*
- *The Canadian rating systems on this unit based on CEA-766-A and the Canadian Radio-Television and Telecommunications Commission (CRTC) policy.*

A. Channel Lock

Particular channels or external input modes can be invisible in this function.

5 Use **[Cursor ▲/▼]** to select "Channel Lock", then press **[ENTER]**.



6 Use **[Cursor ▲/▼]** to select the desired rating, then press **[ENTER]** repeatedly to switch between "View" and "Block".

7 Press **[SETUP]** to exit.

B. MPAA Rating

MPAA Rating is the rating system created by MPAA (Motion Picture Association of America).

5 Use **[Cursor ▲/▼]** to select "MPAA Rating", then press **[ENTER]**.

6 Use **[Cursor ▲/▼]** to select the desired rating, then press **[ENTER]** repeatedly to switch between "View" and "Block".

Rating	Category
X	Mature audience only
NC-17	No one under 17 admitted
R	Restricted; under 17 requires accompanying parent or adult guardian
PG-13	Unsuitable for children under 13
PG	Parental guidance suggested
G	General audience
NR	No rating

7 Press **[SETUP]** to exit.

C. TV Rating

5 Use **[Cursor ▲/▼]** to select "TV Rating", then press **[ENTER]**.



6 Use **[Cursor ▲/▼/◄/►]** to select the desired rating, then press **[ENTER]** repeatedly to switch between "View" and "Block".





7 Press **[SETUP]** to exit.

To set the sub ratings

As for TV-MA, TV-14, TV-PG, or TV-Y7, you can further set the sub ratings to block specific elements of programming. To set the sub ratings, follow the step below.

Use **[Cursor ▲/▼/◄/►]** to select the desired rating, then press **[ENTER]** repeatedly to switch between "View" and "Block".





Rating	Category	
TV-MA	Mature audience only	**higher**
TV-14	Unsuitable for children under 14	
TV-PG	Parental guidance suggested	
TV-G	General audience	
TV-Y7	Appropriate for all children 7 and older	
TV-Y	Appropriate for all children	**lower**

Sub Rating	Category	Rating
FV	Fantasy Violence	TV-Y7
V	Violence	TV-PG TV-14 TV-MA
S	Sexual Situation	
L	Coarse Language	
D	Suggestive Dialogue	TV-PG, TV-14

Note:

- *Blocked sub rating will appear beside the main rating category in "TV Rating" menu.*
- *You cannot block a sub rating (D, L, S or V) if the main rating is set to "View".*
- *Changing the category to "Block" or "View" automatically changes all its sub ratings to the same ("Block" or "View").*

D. New Password

Although the default code "0000" is supplied with the unit, you can set your own PIN Code.

5 Use **[Cursor ▲/▼]** to select "New Password", then press **[ENTER]**.





6 Press **[the Number buttons]** to enter the new 4-digit PIN Code.

- Enter PIN Code again in "Confirm password." entry field.



7 Press **[SETUP]** to exit.

Note:

- *Make sure new PIN Code and confirm PIN Code must be exactly the same. If they are different, the space is cleared for reentering.*
- *Your PIN Code will be erased and return to the default (0000) when a power failure occurs.*
  If you forget the PIN Code, unplug the AC power cord for 10 seconds to restore the PIN Code to 0000.

☑ PC Settings

This function lets you adjust the PC screen position during PC input through the HDMI 1 input jack.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "PC Settings", then press **[ENTER]**.

4 Use **[Cursor ▲/▼]** to select the setting you want to adjust, then press **[ENTER]**.



5 Adjust the setting.

Position Reset

Use **[Cursor ▲/▼]** to select "Reset", then press **[ENTER]**.



- The horizontal/vertical position of the PC screen are automatically adjusted.

Horizontal Position, Vertical Position

Use **[Cursor ◀/▶]** to adjust.

	Cursor ◀	Cursor ▶
Horizontal Position 	to move PC screen left	to move PC screen right
Vertical Position	to move PC screen down	to move PC screen up

6 Press **[SETUP]** to exit.

Note:

- *You may not obtain an appropriate screen with "Position Reset" for some signals. In this case, adjust the settings manually.*

☑ Energy Saving Mode

You can set whether the power consumption is saved or not.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Energy Saving Mode", then press **[ENTER]**.

4 Use **[Cursor ▲/▼]** to select the desired mode, then press **[ENTER]**.



On	Select if you want to reduce the power consumption.
Off	The power consumption may possibly exceed the limited requirement of the ENERGY STAR® qualification.

5 Press **[SETUP]** to exit.

☑ Location

When you select "Retail", the power consumption may possibly exceed the limited requirement of the ENERGY STAR® qualification.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.



3 Use **[Cursor ▲/▼]** to select "Location", then press **[ENTER]**.



4 Use **[Cursor ▲/▼]** to select the desired location, then press **[ENTER]**.

5 Press **[SETUP]** to exit.

☑ Current Software Info

This function shows what version of the software currently used.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DETAIL", then press **[ENTER]**.

3 Use **[Cursor ▲/▼]** to select "Current Software Info", then press **[ENTER]**.





4 Confirm the version of the software currently used.

5 Press **[SETUP]** to exit.

DVD Functions

☑ Playable Media

Media Type	DVD-VIDEO	DVD-RW	DVD-R	CD-DA	CD-RW	CD-R
Logo						
Recorded Signal	digital video (MPEG2)			digital audio		
Media Size	5 inches (12 cm)					

☑ Unplayable Media

NEVER play back the following discs. Otherwise, malfunction may result!
3 inch (8 cm) disc, DVD-RAM, DVD-audio, CD-i, photo CD, Video CD, DVD with region codes other than 1 or ALL, DTS-CD, DVD-ROM for personal computers, CD-ROM for personal computers, the discs with labels, scratches, stains, blemishes, etc., HD DVD, Blu-ray Disc, CD-RW/-R with MP3 files and CD-RW/-R with JPEG files including Kodak Picture CD.

On the following disc, the sound MAY NOT be heard.
super audio CD

Any other discs without compatibility indications

Note:
- *Unfinalized discs cannot be played back.*
- *For DVD-RW/R, discs recorded in the VR (video recording) format cannot be played back. Only the finalized video format discs can be played back.*
- *Some discs cannot be played back because of incompatible recording conditions, characteristics of the recorder or special properties of discs.*
- *Only the sound recorded on the normal CD layer can be delivered. The sound recorded on the high density super audio CD layer cannot be delivered.*
- *Do not use a single CD adaptor which makes 3 inch (8 cm) to 5 inch (12 cm) disc.*
- *You can play back discs with the marks listed in "Playable Media". If you use non-standardized discs, this unit may not play them back or the sound and video quality will be compromised.*
- *If the recorded portion of the disc is too small (less than 2-3/16 inches (55 mm) across), it may not play back properly.*

Region Codes

This unit has been designed to play back DVD with region 1. DVD must be labeled for ALL regions or for region 1 in order to play back on the unit. You cannot play back DVD that are labeled for other regions. Look for the symbols on your DVD. If these region symbols are not on your DVD, you cannot play back the DVD in this unit.

The number inside the globe refers to region of the world.

A DVD labeled for a specific region can only be played back on the unit with the same region code.

Color Systems

DVD is recorded in different color systems throughout the world. The most common color system is NTSC (which is used primarily in the United States and Canada).

This unit uses NTSC, so DVD you play back must be recorded in the NTSC system. You cannot play back DVD recorded in PAL color systems.

These operations are accessible by remote control. Some may also be accessible by controls on the main unit.

☑ Playback

Before you begin:
Turn on the amplifier and any other equipment which is connected to this unit. Make sure the external audio receiver (not included) are set to the correct channel.

1 Press **[POWER]** to turn on the unit.

POWER

2 Insert a disc with label facing forward.



- In case the DVD was recorded on both sides, make sure the label of the side you want to play back is facing forward.

3 The unit switches to the DVD mode when the unit was in TV mode and detects the type of disc.

e.g.) DVD

- Press **[PLAY ▶]** if the unit does not go to the DVD mode.

4 The unit starts playback.
- If playback does not start automatically, press **[PLAY ▶]** again.

5 Press **[STOP ■]** to stop playback temporarily.

STOP

- If playback remains stopped for 20 minutes, the unit will turn itself off automatically when "AUTO POWER OFF" is set to "ON".

6 Press **[EJECT ⏏]** to eject the disc.

EJECT

Note:
- *" ⃠ " may appear at the top-right on the TV screen when the operation is prohibited by the disc or this unit.*

- *Some DVD may start playback from title 2 or 3 due to specific programs.*
- *During the playback of a 2-layered disc, pictures may stop for a moment. This happens while the 1st layer is being switched to the 2nd layer. This is not a malfunction.*
- *When you cannot remove the disc, you may try either following operations.*
  *- Press and hold **[EJECT ⏏]** on the unit for more than 5 seconds.*
  *- Unplug the AC power cord and plug it in again, then press **[EJECT ⏏]**.*
  It will take about 10 seconds to eject the disc, while that the unit will not respond to any key commands.

☑ Disc Menu

DVD

Some discs contain disc menus which describe the contents of the disc or allow you to customize disc playback, or title menu which lists the titles available on the DVD.

To display the DVD menu, press **[DISC MENU]** and use **[Cursor ▲ / ▼ / ◀ / ▶]** to select an item, then press **[ENTER]** (or **[PLAY ▶]**).
To display the top menu, press **[TITLE]** and use **[Cursor ▲ / ▼ / ◀ / ▶]** to select an item, then press **[ENTER]** (or **[PLAY ▶]**).

Note:
- *Menu operations may vary depending on the disc. Refer to the manual accompanying the disc for more details.*

☑ Resume Playback

Press **[STOP ■]** during playback.
Resume message will appear on the TV screen.
Press **[PLAY ▶]**. Playback will resume from the point at which playback was stopped.



Note:
- *To cancel resume, press **[STOP ■]** one more time in the stop mode. On some discs, **[STOP ■]** will not work while the resume message appears. Please wait until the message disappears.*
- *The resume information will be kept even when the unit is turned off. However, ejecting the disc will cancel the resume feature. Playback will start at the beginning the next time you insert the disc.*

☑ Paused and Step-by-step Playback

Press **[PAUSE ❚❚]** during playback.
- Playback will be paused and sound will be muted.

To continue playback, press **[PLAY ▶]**.

DVD

Each time you press **[PAUSE ❚❚]** in the pause mode, the disc goes forward one frame at a time.
To continue playback, press **[PLAY ▶]**.

Note:
- *Set "STILL MODE" to "FIELD" in the "OTHERS" menu if pictures in the pause mode are blurred. (Refer to page 47.)*

☑ Fast Forward / Fast Reverse

Press **[FWD ▶▶]** or **[REV ◀◀]** repeatedly during playback to select the desired forward or reverse speed.
To continue playback, press **[PLAY ▶]**.

◀◀ 1

Note:
- *Set "STILL MODE" to "FIELD" in the "OTHERS" menu if pictures in the fast playback mode are blurred. (Refer to page 47.)*
- *Fast forward / fast reverse speed varies with disc. Approximate speed is 1(2x), 2(8x), 3(20x), 4(50x) and 5(100x) on DVD and 1(2x), 2(8x) and 3(30x) on audio CD.*
- *For DVD, sound will be muted during this function.*
- *For audio CD, sound will be intermittent during the search.*

☑ Slow Forward / Slow Reverse

DVD

Press **[FWD ▶▶]** or **[REV ◀◀]** repeatedly during the paused mode to select the desired forward or reverse speed.
To continue playback, press **[PLAY ▶]**.

I▶ 1

Note:
- *Set "STILL MODE" to "FIELD" in the "OTHERS" menu if pictures in the slow playback mode are blurred. (Refer to page 47.)*
- *Slow forward / slow reverse speed varies with disc. Approximate speed is 1(1/16x), 2(1/8x) and 3(1/2x).*
- *The sound will be muted during this function.*

☑ Zoom

DVD

The zoom function allows you to enlarge the video image and to pan through the enlarged image.

1 During playback, press **[MODE]** repeatedly until "🔍" appears.

MODE



- The picture becomes twice as large.

2 Press **[ENTER]** repeatedly to change the zoom factor, "2x" or "4x".

ENTER



3 Once a desired zoom factor is set, use **[Cursor ▲ / ▼ / ◀ / ▶]** to slide the zoomed picture across the TV screen.





4 To exit zoom, repeat steps 1 to 2 above and press **[ENTER]** repeatedly until "OFF" appears.

ENTER

Note:
- *The gray box with an inner blue box that shows during zoomed playback is the position guide indicates the position of the zoomed image within the overall image. Position guide stays on the TV screen until you press **[ENTER]**. Press **[ENTER]** one more time to recall the position guide when disappears.*
- *Zoom function does not work while the disc menu is displayed.*
- *4x zoom is not available on some discs.*
- *Zoom function is also available during pause mode.*

☑ Search Functions

Chapter / Title / Track Search

You can select chapters, titles or tracks on the disc.

1 During playback, press **[MODE]** repeatedly until "CH" / "TR" appears.
- If you want to perform the title search, use **[Cursor ▲ / ▼]** repeatedly until "TT" appears.

e.g.) DVD



2 Press **[the Number buttons]** to select your desired chapter, title or track within 60 seconds.



To play back a single-digit chapter, title or track when there are more than 10 chapters, titles or tracks, press **[ENTER]** after entering the chapter, title or track number.

3 Playback will start automatically from the chapter, title or track you selected.

Note:
- *Chapter, title or track search can only be performed during playback or when the unit has kept the resume information. It cannot be performed in the stop mode.*
- *The total number of chapters / titles / tracks in your disc; with less than 10 chapters / titles / tracks, press the chapter / title / track number directly. To play a double-digit chapter / title / track, press the chapter / title / track number.*
- *Track search is not available for programmed or random playback.*

Using [SKIP |◀◀ / ▶▶|]

1 During playback, press **[SKIP |◀◀ / ▶▶|]** repeatedly until a desired chapter, title or track will be selected.



2 Playback will start automatically from the chapter, title or track you selected.

Note:
- ***[SKIP |◀◀ / ▶▶|]** are not available when playback is stopped.*

Time Search

You can select the desired time which the disc is played back from.

1 During playback, press **[MODE]** repeatedly until "CH" / "TR" appears.

e.g.) DVD



2 Use **[Cursor ▲/▼]** repeatedly until "🕒" appears.



3 Press **[the Number buttons]** to select your desired time lapse within 60 seconds.



4 Playback will start automatically from the time you selected.

Note:

- *When there is no need to enter a number, "0" appears automatically. For example, "0: 0_: _ _" appears in the time search menu if the total time of the title or track is less than 10 minutes.*
- *Press **[CLEAR]** to erase the incorrect input at step 3.*
- *Time search can only be performed during playback or when the unit has kept the resume information. It cannot be performed in the stop mode.*

Direct Search

Press **[the Number buttons]** to select your desired chapter, title or track.



Note:

- *To select a single-digit chapter, title or track number, press the number directly.*
- *To select double digit chapter, title or track number:*
- *If the disc contains more than 9 and less than 100 chapter, title or track, press **[+10]** first, then enter the double digit chapter, title or track number. (e.g., for track 26, press **[+10]**, **[2]** and **[6]**.)*

☑ Repeat Playback

Repeat function is available only during playback.

1 During playback, press **[MODE]** repeatedly until " " appears.



2 Press **[Cursor ▲ / ▼]** to change the repeat mode.

DVD

- **OFF** (repeat **off**)
- **CHAPTER** (**current chapter** repeat)
- **TITLE** (**current title** repeat)

CD

- **OFF** (repeat **off**)
- **TRACK** (**current track** repeat)
- **ALL** (**entire disc** repeat)

3 Press **[BACK]** to exit.

☑ Repeat A-B Playback

You can repeat playback between A and B on a disc.

1 During playback, press **[MODE]** repeatedly until " A-B " appears.



2 Press **[ENTER]** at your desired starting point (A).



3 Press **[ENTER]** at your desired ending point (B).



- Point B should be in the same title or track as point A.
- Within a few seconds, the section A-B will begin to play back repeatedly.

4 To cancel repeat A-B playback, press **[MODE]** repeatedly until " A-B " appears.
Press **[ENTER]** so "OFF" appears.

Note:

- *Repeat setting (except "ALL") will be cleared when moving to another title or chapter, track.*
- *During programmed playback, repeat setting will be effective for the tracks in the program.*
- *Repeat playback or repeat A-B playback may not available with some discs.*
- *Repeat A-B playback does not function during other repeat mode.*
- *To cancel point A, press **[CLEAR]** at step 2 in "Repeat A-B Playback".*
- *Stopping playback will cancel repeat A-B playback.*

☑ Random Playback

CD

This function shuffles the playing order of tracks instead of playback in the sequence.

1 In stop mode, press **[MODE]** repeatedly until "RANDOM" menu appears.



2 Press **[PLAY ▶]** to start random playback.



Note:

- *To repeat the current track in the random mode, follow the steps 1 and 2 in "Repeat Playback" on page 39 and select " TRACK".*
- *To repeat the entire random selections, follow the steps 1 and 2 in "Repeat Playback" on page 39 and select " ALL".*

☑ Programmed Playback

CD

You may determine the order in which tracks will play back.

1 In stop mode, press **[MODE]** repeatedly until "PROGRAM" menu appears.



2 Use **[Cursor ▲ / ▼]** to select a desired track, then press **[ENTER]** to store.

- Additional tracks may be on other screens. Use **[Cursor ▲ / ▼]** to go on to the next / previous pages.
- Repeat this step until you have selected all the tracks you wish to play back in the program.



- Up to 99 tracks can be ordered.
- If 8 or more tracks were in a program, use **[SKIP |◀◀ / ▶▶|]** to see all the tracks.

3 Press **[PLAY ▶]** to start programmed playback.



Note:

- *Press **[CLEAR]** to erase the last track in the program if you make an error.*
- *To erase all programmed tracks at once, select "ALL CLEAR" and press **[ENTER]** at step 2.*
- *While a program is being played back, **[STOP ■]** works as follows:*
  - *Pressing **[STOP ■]** once: The track will be in the resume standby mode. Next time you press **[PLAY ▶]**, the playback will resume from the point where it is stopped in the programmed playback.*
  - *Pressing **[STOP ■]** twice: Resume mode will be canceled. Next time you press **[PLAY ▶]**, playback will restart from the first track in the original order. However, your programmed playback can be restarted when you follow the above steps. (Your programs are still stored until either the disc is ejected or the unit is turned off.)*
  - *On some discs, **[STOP ■]** will not work while the resume message appears. Please wait until the message disappears.*
- *To repeat the current track in the program, follow the steps 1 and 2 in "Repeat Playback" on page 39 and select "TRACK".*
- *To repeat the entire program, follow the steps 1 and 2 in "Repeat Playback" on page 39 and select "ALL".*
- *Turning off the unit or ejecting the disc will erase the program.*
- *You cannot use **[the Number buttons]** to select another track during programmed playback. Use **[SKIP |◀◀ / ▶▶|]** to select other tracks in the program.*
- *You cannot combine random playback with programmed playback.*
- *You cannot alter a programmed order during playback.*
- *You can start programmed playback only while in "PROGRAM" menu.*

☑ On-screen Display

You can check the information about the current disc by pressing [INFO] on the remote control.

DVD


INFO
1
CH 11/16 0:00:00 - 0:03:30
appears only when multi-angle is available on the DVD
current playback status
remaining time of the current chapter
elapsed time of the current chapter
CH (Chapter): current chapter number / total chapters
INFO
2
TT 1/3 0:00:00 - 1:23:45
remaining time of the current title
elapsed time of the current title
TT (Title): current title number / total titles
INFO
3
T L1
layer number, appears only when playing a 2-layered disc
L0 : Layer 0 is playing
L1 : Layer 1 is playing
current repeat setting appears only when the repeat setting is active
C : Chapter repeat
T : Title repeat
A B : A-B repeat
bit rate indication for the amount of audio and video data currently being read
INFO
4

CD


INFO
1
TR 4/12 0:03:21 - 0:02:15 T
current playback status
remaining time of the current track
elapsed time of the current track
TR (Track): current track number / total tracks
INFO
2
ALL 4/12 0:13:45 - 0:45:40 T
ALL: current track number / total tracks
current repeat setting appears only when the repeat setting is active
T : Track repeat
A : All tracks repeat
A B : A-B repeat
remaining time of the entire disc
elapsed time of the entire disc
INFO
3

Note:

- *When you are playing back an audio CD in program or random mode, " TR PROGRAM" (or " TR RANDOM") will be displayed instead of 2.*

☑ Special Settings

Subtitle Language

DVD

This unit allows you to select a subtitle language (if available) during DVD playback.

1 During playback, press **[MODE]** repeatedly until " " appears.

2 Use **[Cursor ▲/▼]** repeatedly until your desired language appears.



- Each time you press **[Cursor ▲/▼]**, the subtitle language changes as shown on the next page.



3 Press **[BACK]** to exit.

Note:

- *To cancel the subtitle, select "OFF" at step 2.*
- *If your language is not shown after pressing **[Cursor ▲ / ▼]** several times, the disc may not have that language. However, some discs allow you to change subtitle languages setting in the disc menu. (Operation varies depending on the disc, so refer to the manual along with the disc.)*
- *When "NOT AVAILABLE" appears on the TV screen, it means no subtitle is recorded on the scene.*
- *If you choose a language that has 3-letter-language code, the code will be displayed every time you change the subtitle language setting. If you choose any other languages, "---" will be displayed instead. (Refer to page 48.)*
- *Ejecting the disc will cancel your subtitle setting.*

Audio Language

DVD

This unit allows you to select an audio language (if multiple languages are available) during DVD playback.

During playback, press **[AUDIO]** repeatedly until the desired language appears.



- Each time you press **[AUDIO]**, the audio language changes as example below.



Note:

- *Some discs will only allow you to change the audio setting from the disc menu. Refer to the manual accompanying the discs for details.*
- *If your language is not shown after pressing **[AUDIO]** several times, the disc may not have that language. However, some discs allow you to change multiple audio languages setting in the disc menu. (Operation varies depending on the disc, so refer to the manual along with the disc.)*
- *When "NOT AVAILABLE" appears on the TV screen, it means audio language is not available.*

Camera Angles

DVD

Some DVD may contain scenes which have been shot simultaneously from various angles. You can change the camera angle if " " appears on the screen. If "ANGLE ICON" is set to "OFF" in "OTHERS" menu, " " will not appear. (Refer to page 47.)

1 During playback, press **[MODE]** repeatedly until " " appears.

2 Use **[Cursor ▲ / ▼]** repeatedly until your desired camera angle appears.



3 Press **[BACK]** to exit.

Black Level Setting

DVD

Adjust the black level to make the dark areas of the TV picture brighter.

1 During playback, press **[MODE]** repeatedly until " " appears.



2 Press **[Cursor ▲ / ▼]** to adjust the black level.



ON : Makes the dark areas brighter.
OFF: Shows the original picture as recorded.

3 Press **[BACK]** to exit.

Note:

- *The setting will be kept even if the unit is turned off.*

Stereo Sound Mode

CD

This unit allows you to select a sound mode during CD playback.

During playback, press **[AUDIO]** repeatedly until the desired sound mode appears.



- Each time you press **[AUDIO]**, the sound mode changes as example below.



STEREO (stereo sound with left and right channels)
L-ch (left channel sound only)
R-ch (right channel sound only)

Note:
- *Virtual surround cannot be changed when the sound mode is set to either "L-ch" or "R-ch".*

Virtual Surround

You can enjoy virtual surround on your 2 channel stereo system.

1 During playback, press **[MODE]** repeatedly until " " appears.



2 Press **[Cursor ▲/▼]** to select the sound level.



1 : Natural effect.
2 : Emphasized effect.
OFF : No effects (original sound).

3 Press **[BACK]** to exit.

Note:
- *The setting will be kept even if the unit is turned off.*
- *For audio CD, virtual surround will not be effective if the sound mode is set to something other than "STEREO". (Refer to "Stereo Sound Mode" on page 43.)*
- *Turn down the level or select "OFF" if the sound is distorted.*

Marker Setup

This feature allows you to assign a specific point on a disc to be called back later.

To set a marker

1 During playback, press **[MODE]** repeatedly until "CH" / "TR" appears.



2 Use **[Cursor ▲/▼]** repeatedly until marker search menu appears.



3 Use **[Cursor ◄/►]** to select an available marker within 60 seconds.



4 When the playback reaches the point at which you want to set a marker, press **[ENTER].**
- Marker is now set.



5 Press **[BACK]** to exit.

To return to the marker later

1 Repeat steps 1-2 in "To set a marker". Use **[Cursor ◄/►]** to select the desired marker.



2 Press **[ENTER]** at the desired marker to restart playback from the specific point which you set.



Note:
- *Marker search menu will disappear in about 60 seconds when there is no input.*
- *You can mark up to 10 points.*
- *To clear a marker, select the marker to be cleared, and then press **[CLEAR]**.*
- *Ejecting the disc or turning off the power will erase all markers.*
- *Selecting " AC " at step 3 in the section "To set a marker" will also erase all markers.*

Settings are only effective when the unit is in DVD mode and any discs should not be played back.

☑ DVD Language Setting

You can change the desired language when playing back the disc.

1 Press **[SETUP]** to display the main menu.



2 Use **[Cursor ▲/▼]** to select "DVD", then press **[ENTER]**.

3 Use **[Cursor ◄/►]** to select " ", then press **[ENTER]**.

4 Use **[Cursor ▲/▼]** to select the desired item, then press **[ENTER]**.



5 Use **[Cursor ▲/▼]** to select the desired item, then press **[ENTER]**.

AUDIO *1, *2 (Default: ORIGINAL)
Select the desired audio language.



SUBTITLE *1, *2 (Default: OFF)
Select the desired subtitle language.



DISC MENU *1 (Default: ENGLISH)
Select the desired language in DVD menu.



Note:

- *To change the on-screen language, call up "LANGUAGE" from the main menu and set the desired language. (Refer to "Language Selection" on page 22.)*

***1**

- *Language options are not available with some discs.*
- *If "OTHER" is selected in "AUDIO", "SUBTITLE" or "DISC MENU" menu, press 4-digit number to enter the code for the desired language. (Refer to "Language Code List" on page 48.)*
- *Only the languages supported by the disc can be selected.*

***2**

- *Language setting for Audio and Subtitle are not available with some discs.*
  *- Use **[MODE]** to select subtitles available on the DVD.*
  *- Use **[AUDIO]** to select audio available on the DVD.*
- *If the DVD's default settings for audio and subtitle are the same language, the subtitles may not show unless you turn them on.*

6 Press **[SETUP]** to exit.

☑ DVD Audio Setting

Choose the appropriate audio settings for your equipment. It only affects during the playback of DVD.

1 Press **[SETUP]** to display the main menu.



2 Use **[Cursor ▲/▼]** to select "DVD", then press **[ENTER]**.



3 Use **[Cursor ◄/►]** to select " " , then press **[ENTER]**.



4 Use **[Cursor ▲/▼]** to select the desired item, then press **[ENTER]**.

DRC (dynamic range control) (Default: ON)

This function is available only on the discs which are recorded in the Dolby Digital format.



ON : Compress the range between soft and loud sounds.
OFF : No effects (original sound).

DOWN SAMPLING (Default: ON)

This function is available only on digital outputting of a disc recorded in 96kHz.



ON : When outputting in 48kHz.
OFF : When outputting the original sound.

> ***Note:***
> • *When playing back a 96 kHz disc with the copyright protection or when "Virtual Surround" is set to "1" or "2", the sound will be down sampled at 48 kHz even if the "DOWN SAMPLING" is set to "OFF".*
> *(Refer to "Virtual Surround" on page 43.)*

DOLBY DIGITAL (Default: BITSTREAM)

Set to "BITSTREAM" when this unit is connected to a Dolby Digital decoder.



BITSTREAM : Outputs Dolby Digital signals.
PCM : Converts the Dolby Digital into PCM. (2 channel)

5 Press **[SETUP]** to exit.

☑ Parental Setting

Parental setting prevents your children from viewing inappropriate materials. (password protected.) Playback will stop if the ratings exceed the levels you set.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DVD", then press **[ENTER]**.



3 Use **[Cursor ◄/►]** to select " ", then press **[ENTER]**.



4 Use **[the Number buttons]** to enter the 4-digit numbers for your password, then press **[ENTER]**.



- If you have set password already, use **[the Number buttons]** to enter the current 4-digit password.
- You cannot use the default password (4737) to play back a DVD.

5 Use **[Cursor ▲/▼]** to select the "PARENTAL LEVEL", then press **[ENTER]**.



6 Use **[Cursor ▲/▼]** to select the desired item, then press **[ENTER]**.



PARENTAL LEVEL

ALL :	All parental locks are cancelled.
8 [ADULT] :	All ratings (adult / general / children) can be played back.
7 [NC-17]-2 [G] :	Only DVD intended for general use and children can be played back.
1 [KID SAFE] :	Only DVD intended for children can be played back.

7 Press **[SETUP]** to exit.

To change the password

5 Follow steps 1 to 4. Use **[Cursor ▲/▼]** to select "PASSWORD CHANGE", then press **[ENTER]**.



6 Use **[the Number buttons]** to enter the new 4-digit password.



Note:

- *DVD-video may not respond to parental lock settings. Make sure this function works with your DVD-video.*
- *Record the password in case you forget it.*
- *If you forget the password, press **[4]**, **[7]**, **[3]**, **[7]**, then enter your new password. Password will be cleared and parental levels will be set to "ALL".*
- *A power failure will not erase your password.*

7 Press **[SETUP]** to exit.

☑ Others

You can change the other functions.

1 Press **[SETUP]** to display the main menu.

2 Use **[Cursor ▲/▼]** to select "DVD", then press **[ENTER]**.



3 Use **[Cursor ◄/►]** to select " ", then press **[ENTER]**.



4 Use **[Cursor ▲/▼]** to select the desired item, then press **[ENTER]**.

ANGLE ICON (Default: ON)
Set to "ON" to show the angle icon when multiple camera angles are available during DVD playback.



STILL MODE (Default: AUTO)
Set the picture quality in the still mode.
If you select "AUTO", it automatically selects the best resolution setting ("FRAME" or "FIELD") based on the date characteristics of the pictures.

FIELD : The picture in the still mode will be stabilized.
FRAME : The picture in the still mode will be highly defined.



AUTO POWER OFF (Default: ON)
Set to "ON" to turn this unit off automatically after 20 minutes of no use.



5 Press **[SETUP]** to exit.

☑ Reset to the Default Setting

You can reset all the settings except for the parental setting and on-screen menu language.

1 Press **[SETUP]** to display the main menu.



2 Use **[Cursor ▲/▼]** to select "DVD", then press **[ENTER]**.



3 Use **[Cursor ◄/►]** to select " INITIALIZE ", then press **[ENTER]**.

4 Use **[Cursor ▲/▼]** to select "YES", then press **[ENTER]**.



Note:

- *When you want to cancel the initialization, select "NO" at step 4, then press **[ENTER]**.*

5 Press **[SETUP]** to exit.

☑ Language Code List

Language	Code
A-B	
Abkhazian	4748
Afar	4747
Afrikaans	4752
Albanian	6563
Amharic	4759
Arabic	4764
Armenian	5471
Assamese	4765
Aymara	4771
Azerbaijani	4772
Bashkir	4847
Basque	5167
Bengali;Bangla	4860
Bhutani	5072
Bihari	4854
Bislama	4855
Breton	4864
Bulgarian	4853
Burmese	5971
Byelorussian	4851
C-E	
Cambodian	5759
Catalan	4947
Chinese [CHI]	7254
Corsican	4961
Croatian	5464
Czech [CZE]	4965
Danish [DAN]	5047
Dutch [DUT]	6058
English [ENG]	5160
Esperanto	5161
Estonian	5166
F-H	
Faroese	5261
Fiji	5256
Finnish [FIN]	5255
French [FRE]	5264
Frisian	5271
Galician	5358
Georgian	5747
German [GER]	5051
Greek [GRE]	5158
Greenlandic	5758
Guarani	5360
Gujarati	5367
Hausa	5447
Hebrew	5569
Hindi	5455
Hungarian [HUN]	5467
I-K	
Icelandic [ICE]	5565
Indonesian	5560
Interlingua	5547
Interlingue	5551
Inupiak	5557
Irish [IRI]	5347
Italian [ITA]	5566
Japanese [JPN]	5647
Javanese	5669
Kannada	5760
Kashmiri	5765
Kazakh	5757
Kinyarwanda	6469
Kirghiz	5771
Kirundi	6460
Korean [KOR]	5761
Kurdish	5767
L-N	
Laothian	5861
Latin	5847
Latvian;Lettish	5868
Lingala	5860
Lithuanian	5866
Macedonian	5957
Malagasy	5953
Malay	5965
Malayalam	5958
Maltese	5966
Maori	5955

Language	Code
Marathi	5964
Moldavian	5961
Mongolian	5960
Nauru	6047
Nepali	6051
Norwegian [NOR]	6061
O-R	
Occitan	6149
Oriya	6164
Oromo(Afan)	6159
Panjabi	6247
Pashto;Pushto	6265
Persian	5247
Polish [POL]	6258
Portuguese [POR]	6266
Quechua	6367
Rhaeto-Romance	6459
Romanian [RUM]	6461
Russian [RUS]	6467
S	
Samoan	6559
Sangho	6553
Sanskrit	6547
Scots Gaelic	5350
Serbian	6564
Serbo-Croatian	6554
Sesotho	6566
Setswana	6660
Shona	6560
Sindhi	6550
Singhalese	6555
Siswat	6565
Slovak	6557
Slovenian	6558
Somali	6561
Spanish [SPA]	5165
Sundanese	6567
Swahili	6569
Swedish [SWE]	6568
T	
Tagalog	6658
Tajik	6653
Tamil	6647
Tatar	6666
Telugu	6651
Thai	6654
Tibetan	4861
Tigrinya	6655
Tonga	6661
Tsonga	6665
Turkish [TUR]	6664
Turkmen	6657
Twi	6669
U-Z	
Ukrainian	6757
Urdu	6764
Uzbek	6772
Vietnamese	6855
Volapuk	6861
Welsh	4971
Wolof	6961
Xhosa	7054
Yiddish	5655
Yoruba	7161
Zulu	7267

Note:

- *If you choose a language that has a 3-letter abbreviation, the code will be displayed every time you change the audio or subtitle language setting above. If you choose any other language, '---' will be displayed instead. (3-letter abbreviation is written in bracket.)*

☑ FAQ

Question	Answer
My remote control does not work. What should I do?	• Check the antenna or cable connection to the main unit. • Check the batteries of the remote control. • Check if there is an obstacle between the infrared sensor window and the remote control. • Test the signal output. If OK, then possible infrared sensor trouble. (Refer to "IR Signal Check" on page 52.) • Aim the remote control directly at the infrared sensor window on the front of the unit. • Reduce the distance to the unit. • Re-insert the batteries with their polarities (+/– signs) as indicated. • When there is an infrared-equipped device such as PC near this unit, it may interrupt the remote control signal of this unit. • Move the infrared-equipped device away from this unit, change the angle of the infrared sensor or turn off the infrared communication function.
How come the Initial setup appears every time I turn on this unit?	• Connect the RF coaxial cable to the unit directly and run the initial setup. • Make sure to complete the channel scan before turning off the unit.
Why I cannot watch some TV programs?	• Make sure autoscan has been completed. (Refer to "Autoscan" on page 20.) • Autoscan must be completed when you set up the unit for the first time or move it to a location where previously unavailable channels are broadcast. • The selected channel may not be broadcasting. • When autoscan is interrupted and not completed, some channels will not be received. Make sure to complete. (Refer to "Autoscan" on page 20.) • The selected channel cannot be viewed by the "Child Lock" setting. (Refer to "Child Lock" on page 28.) • The unit requires some kind of antenna input. An indoor antenna (VHF / UHF), an external antenna (VHF /UHF) or an RF coaxial cable from your wall cable/satellite box needs to be plugged into the unit.
How come there is no image from the connected external devices?	• Check if the right input mode is selected by pressing **[INPUT SELECT]** or using **[CHANNEL – / +]**. (Refer to "Switching Each Input Mode" on page 17.) • Check the antenna or cable connection to the unit. • When using the Composite Video Connection check that the Green (Y), Blue (Pb/Cb) and Red (Pr/Cr) connectors are connected to their corresponding colored jacks on the unit.
Whenever I entered channel number, it changes automatically.	• Many digital channels have alternate channel numbers. The unit changes the numbers automatically to the ones signifying the broadcasting stations. These are the numbers used for analog broadcasts.
My disc cannot be played back. Is there any way I can play my disc?	• Clean the disc. • Ensure the disc is correctly inserted. • Check if the disc is defective by trying another disc. • Cancel the parental lock or change the control level. • Insert a correct disc that plays back on this unit. • Handle a disc with special care so that it does not have fingerprints, scratches or dusts on its surface.
Why are captions not displayed entirely? Or, captions are delayed behind the dialogue.	• Captions that are delayed a few seconds behind the actual dialogue are common for live broadcasts. Most captioning production companies can display a dialogue to maximum of 220 words per minute. If a dialogue exceeds that rate, selective editing is used to insure that the captions remain up-to date with the current TV screen dialogue.
How can I set the clock ?	• There is no clock function on this unit.

☑ Troubleshooting Guide

If the unit does not perform properly when operated as instructed in this manual,
check the following chart and all connections once before calling for service.

	Symptom	Remedy
TV	No power	• Make sure the AC power cord is plugged in. • Make sure that the AC outlet supplies the proper voltage, plug another electrical appliance into the AC outlet. • If a power failure occurs, unplug the AC power cord for 1 minute to allow the unit to reset itself.
	Control button does not work.	• Press only one button at a time. Do NOT press more than one buttons at the same time.
	Power is ON but no screen image.	• Check whether the connection of the antenna, cable receiver or satellite box is connected correctly. • Check whether all the cables to the unit are connected to the correct output jack of your device like BD/DVD recorder. • Make sure that the selected input mode is connected to the working input jack. • Check if your computer is NOT in sleep mode when the input mode of this unit is in PC mode. Tap any key on the keyboard to wake up your computer.
	No picture or sound	• Check if the power is on. • Check if the right input mode is selected. • Check whether all the cables to the unit are connected to the correct output jack of your device like BD/DVD recorder. • View other TV channels. The problem might be limited to the broadcasting station. • Turn off the unit and wait for about 1 minute, then turn on the unit again. • Check whether the connection of the antenna, cable receiver or satellite box is connected correctly. • Make sure that the selected input mode is connected to the working input jack. • Check if your computer is NOT in sleep mode when the input mode of this unit is in PC mode. Tap any key on the keyboard to wake up your computer. • Make sure that the sound is not muted. Press **[MUTE]** so that the volume bar and current volume level will appear on the TV screen. • Make sure that the volume is NOT set to "0" or "Mute". If so, use **[VOLUME – / +]** to adjust the desired volume.
	No color	• View other TV channels. The problem might be limited to the broadcasting station. • Adjust "Color" in the main menu.
	Adjusted "PICTURE" or "SOUND" is not effective every time turn on the unit.	• You must set "Home" in "Location" (Refer to page 33). Otherwise, the settings you adjusted will not be memorized after you turn off the unit.
	Sound OK, picture poor	• Electrical interference from nearby appliances may affect picture quality. • Adjust "Contrast" and "Brightness" in the main menu. • View other TV channels. The problem might be limited to the broadcasting station. • For the best picture quality, watch "high definition" wide screen programs. If the HD content is not available, watch "standard definition" programs instead.
	Picture OK, sound poor	• View other TV channels. The problem might be limited to the broadcasting station. • Check if the audio cable is connected in correctly .
	You see a distorted picture or hear an unusual sound.	• You may be getting interference from electrical appliances, automobiles, motorcycles or fluorescent lights. • Try moving the unit to another location to see if this is the cause of the problem.
	Ghosts, lines or streaks in picture	• Electrical interference from nearby appliances may affect picture quality. • View other TV channels. The problem might be limited to the broadcasting station.
	You see "noise" or "trash" on the screen.	• When the capabilities of the unit exceed the capabilities of the digital broadcasting, the signal will be increased to match the capabilities of the display of the unit. This may cause noise or trash.
	Different color marks on the TV screen	• View other TV channels. The problem might be limited to the broadcasting station.

	Symptom	Remedy
TV	You switch to a different input and the volume.	• This unit will memorize the volume level from the last time you adjusted it. • If the volume of the sound from another device is higher or lower, then the loudness will change.
TV	You switch to a different input and the screen size changes.	• This unit will memorize the viewing mode from the last time you used the particular input modes.
TV	The display image does not cover the entire screen.	• If you are using the unit as a PC monitor, make sure that "Horizontal Position" and "Vertical Position" in "PC Settings" are set correctly. • If you are watching TV or using the video, S-video, component video or HDMI with 480i input, press **[SCREEN MODE]** repeatedly to switch various screen modes.
TV	Captions are displayed as a white box. No caption is displayed in the Closed Caption-supported program.	• Interference from buildings or weather conditions may cause captioning to be incomplete. • Broadcasting station may shorten the program to insert advertisement. The closed caption decoder cannot read the information of the shortened program.
TV	No caption is displayed when playing back a disc or a cassette tape containing captions.	• The disc or cassette tape may be illegally copied, or the caption signal might not have been read during copying.
TV	Black box is displayed on the TV screen.	• The text mode is selected for caption. Select "CC1", "CC2", "CC3", "CC4" or "Off".
DVD	Completely distorted picture or black/white picture with DVD.	• Make sure the disc is compatible with the unit.
DVD	Picture freezes momentarily during playback.	• Check the disc for finger prints/scratches and clean with a soft cloth wiping from center to edge.
DVD	Disc cannot be played.	• Clean the disc. • Ensure the disc is correctly inserted. • Check if the disc is defective by trying another disc. • Cancel the parental lock or change the control level. • Insert a correct disc that plays on this unit. • Handle a disc with special care so that it does not have fingerprints, scratches, or dusts on its surface.
DVD	Buttons do not work or the unit stops responding.	• To completely reset the unit, unplug the AC power cord from the power outlet for 5-10 seconds.
DVD	The unit does not respond to some operating commands during playback.	• Operations may not be permitted by the disc. Refer to the instructions of the disc.
DVD	Angle does not switch.	• The angle cannot be switched for DVD which do not contain multiple angles. In some cases multiple angles are only recorded for specific scenes.
DVD	Playback does not start when the title is selected.	• Check the "PARENTAL" setting.
DVD	The password for rating level has been forgotten.	• Enter the default password "4737", then your forgotten password will be cleared.

Note:

- *The LCD panel is manufactured to provide many years of useful life. Occasionally a few non active pixels may appear as a fixed point of blue, green or red. This is not to be considered a defect in the LCD screen.*
- *Some functions are not available in specific modes, but this is not a malfunction. Read the description in this manual for more details on correct operations.*
- *Some functions are prohibited on some discs.*

☑ Glossary

ATSC

Acronym that stands for Advanced Television Systems Committee and the name of the digital broadcasting standards.

Aspect Ratio

The width of a TV screen relative to its height. Conventional TVs are 4:3 (in other words, the TV screen is almost square); widescreen models are 16:9 (the TV screen is almost twice as wide as its height).

CEC (Consumer Electronics Control)

This allows you to operate the linked functions between our brand devices with CEC feature and this unit.

Component Video

This is a video signal format that conveys each of 3 principal colors of light (red, blue and green) through different signal lines. This allows the viewers to experience picture colors as original as it is. There are several signal formats, including Y / Pb / Pr and Y / Cb / Cr.

Dolby Digital

The system developed by Dolby Laboratories to compress digital sound. It offers stereo sound (2ch) or multi-channel audio.

HDMI (High-Definition Multimedia Interface)

Interface that supports all uncompressed, digital audio/video formats including set-top box, BD/DVD recorder or digital television, over a single cable.

HDTV (High Definition TV)

Ultimate digital format that produces high resolution and high picture quality.

NTSC

Acronym that stands for National Television Systems Committee and the name of the current analog broadcasting standards. Off the air NTSC signals will no longer be sent by broadcasting stations after Feb 17, 2009.

Password / PIN Code

A stored 4-digit number that allows access to parental control features.

Region Code

Regions associate discs and players with particular areas of the world.
This unit will only play back discs that have compatible region codes.
You can find the region code of your unit by looking on the rear panel.
Some discs are compatible with more than one region (or all regions).

SAP (Secondary Audio Program)

Second-audio channel delivered separately from main-audio channel. This audio channel is used as an alternate in bilingual broadcasting.

SDTV (Standard Definition TV)

Standard digital format that is similar to the NTSC picture quality.

S-video

Offers higher quality images by delivering each signal, color (c) and luminance (y) independently of each other through a separate cable.

☑ Maintenance

Cabinet Cleaning

- Wipe the front panel and other exterior surfaces of the unit with a soft cloth immersed in lukewarm water and wrung dry.
- Never use a solvent or alcohol. Do not spray insecticide liquid near the unit. Such chemicals may cause damage and discoloration to the exposed surfaces.

Panel Cleaning

Wipe the panel of the unit with a soft cloth. Before cleaning the panel, disconnect the AC power cord.

Disc Handling

Handle the discs so that fingerprints and dust do not adhere to the surfaces of the discs.



- Always store the disc in its protective case when it is not used.
- To clean-off, use a soft cloth.
- Do not use a hard cloth since this will mar the disc.
- Wipe the disc in a straight line form center to edge.
- Never wipe with a circular motion.





- Do not use detergent or abrasive cleaning agents.

Servicing

Should your unit become inoperative, do not try to correct the problem yourself. There are no user serviceable parts inside. Turn off the unit, unplug the AC power cord and call our toll free customer support line found on the cover of this manual to locate an authorized service center.

If the Laser Optical Pickup Unit is Dirty

If the unit still does not perform properly when it is operated, while referring to the relevant sections and to "Troubleshooting Guide" in this owner's manual, the laser optical pickup unit may be dirty. Consult your dealer or an Authorized Service Center for inspection and cleaning of the laser optical pickup unit.

IR Signal Check

If the remote control is not working properly, you can use a digital camera (including a cellular phone with built-in camera) to see if it is sending out an infrared signal.

- With a digital camera (including built-in cell phone cameras): Point the Digital Camera towards the remote control infrared diode at the front of the remote control. Press any button on the remote control and look through the camera display. If the infrared pulsating light appears through the camera, the remote control is sending out an IR signal.

☑ Cable Channel Designations

If you subscribe to cable TV, the channels are displayed as 1-135. Cable companies often designate channels with letters or letter-number combinations. Please check with your local cable company. The following is a chart of common cable channel designations.

CATV channel	5A	2	3	4	5	6	7	8	9	10	11	12	13	A	B	C	D	E	F	G	H
TV Display	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
CATV channel	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	W+1	W+2	W+3	W+4	W+5	W+6
TV Display	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42
CATV channel	W+7	W+8	W+9	W+10	W+11	W+12	W+13	W+14	W+15	W+16	W+17	W+18	W+19	W+20	W+21	W+22	W+23	W+24	W+25	W+26	W+27
TV Display	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
CATV channel	W+28	W+29	W+30	W+31	W+32	W+33	W+34	W+35	W+36	W+37	W+38	W+39	W+40	W+41	W+42	W+43	W+44	W+45	W+46	W+47	W+48
TV Display	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84
CATV channel	W+49	W+50	W+51	W+52	W+53	W+54	W+55	W+56	W+57	W+58	A-5	A-4	A-3	A-2	A-1	W+59	W+60	W+61	W+62	W+63	W+64
TV Display	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105
CATV channel	W+65	W+66	W+67	W+68	W+69	W+70	W+71	W+72	W+73	W+74	W+75	W+76	W+77	W+78	W+79	W+80	W+81	W+82	W+83	W+84	W+85
TV Display	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126
CATV channel	W+86	W+87	W+88	W+89	W+90	W+91	W+92	W+93	W+94												
TV Display	127	128	129	130	131	132	133	134	135												

☑ General Specifications

TV

TV format: ATSC / NTSC-M TV standard
Closed caption system:
§15.122/FCC (digital CC)
§15.119/FCC (analog CC)
Channel coverage (ATSC/NTSC):
Terrestrial **VHF:** 2~13 **UHF:** 14~69
CATV 2~13, A~W,
W+1~W+94 (analog W+1~W+84),
A-5~A-1, 5A
Tuning system: Channel frequency synthesized tuning system
Channel access: Direct access keyboard,
Programmable scan, and up/down

DVD

Discs (playback compatibility):
DVD-video, DVD-RW/-R,
audio CD, CD-RW/-R
Frequency response:
DVD (linear sound): 20 Hz to 20 kHz (sample rate: 48 kHz)
20 Hz to 44 kHz (sample rate: 96 kHz)
CD: 20 Hz to 20 kHz
Signal-to-noise ratio (S/N ratio):
CD: 90 dB (JEITA)
Total distortion factor:
DVD: 1 KHz 0.007% (JEITA)
CD: 1 KHz 0.007% (JEITA)

☑ Electrical Specification

Sound Output: 10W, 8Ω x 2

☑ Other Specifications

Terminals:

Antenna input:	VHF/UHF/CATV	75Ω unbalanced (F-type)
Audio input:	RCA jack (L/R) x 6	500mV rms
Video input:	RCA jack x 1	1V p-p (75Ω)
S-video input:	Mini DIN 4-pin jack x 1	**Y:** 1V p-p (75Ω)
		C: 286mV p-p (75Ω)
Component video input:		
	RCA jack x 3	**Y:** 1V p-p (75Ω)
		Pb/Cb:700mV p-p (75Ω)
		Pr/Cr: 700mV p-p (75Ω)
HDMI input:	HDMI 19pin x 2	
Coaxial digital audio output:		
	RCA jack x1	500mV p-p (75Ω)
Audio output:	RCA jack (L/R) x 2	500mV rms

Remote control: Digital encoded infrared light system
Operating temperature:
41°F (5°C) to 104°F (40°C)
Power requirements:
120V~ AC +/- 10%, 60Hz +/- 0.5%

Power consumption (maximum):
160W
LCD: 32 inches class (31.5 inches measured diagonally)

Dimensions:	<without stand>		<with stand>	
W:	30.0 inches	(760.0mm)	30.0 inches	(760.0mm)
H:	20.5 inches	(519.3mm)	22.2 inches	(563.0mm)
D:	5.1 inches	(127.5mm)	9.3 inches	(234.0mm)
Weight:	20.6 lbs.	(9.3kg)	21.7 lbs.	(9.8kg)

- Designs and specifications are subject to change without notice and without our legal obligation.
- If there is a discrepancy between languages, the default language will be English.

TO OUR VALUED CUSTOMER

THANK YOU FOR PURCHASING THIS JVC PRODUCT.

WE WANT TO HELP YOU ACHIEVE A PERFECT EXPERIENCE.

NEED HELP ON HOW TO HOOK UP?
NEED ASSISTANCE ON HOW TO OPERATE?
NEED TO LOCATE A JVC SERVICE CENTER?
LIKE TO PURCHASE ACCESSORIES?

JVC® IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

http://www.jvc.com

Remember to retain your Bill of Sale for Warranty Service.

Do not attempt to service the product yourself

Caution

To prevent electrical shock, do not open the cabinet.
There are no user serviceable parts inside.
Please refer to qualified service personnel for repairs.

BT-51018-6C
(1008)

JVC®

LIMITED WARRANTY

1-1 USA ONLY

ONLY FOR PRODUCT PURCHASED IN U.S.A.

JVC Americas Corp. (JVC) warrants this product and all parts thereof, except as set forth below ONLY TO THE ORIGINAL RETAIL PURCHASER to be FREE FROM DEFECTIVE MATERIALS AND WORKMANSHIP from the date of original purchase for the period shown below. ("The Warranty Period")

PARTS	LABOR
1 YR	1 YR

THIS LIMITED WARRANTY IS VALID ONLY IN THE FIFTY (50) UNITED STATES, THE DISTRICT OF COLUMBIA AND IN THE COMMONWEALTH OF PUERTO RICO.

WHAT WE WILL DO:

If this product is found to be defective within the warranty period, JVC will repair or replace defective parts with new or rebuilt equivalents at no charge to the original owner. Such repair and replacement services shall be rendered by JVC during normal business hours at JVC authorized service centers. Parts used for replacement are warranted only for the remainder of the Warranty Period. All products may be brought to a JVC authorized service center on a carry-in basis. Color televisions with a screen size of 37"class or greater qualify for in-home service. In such cases, a technician will come to your home and either repair the TV there or remove and return it if it cannot be repaired in your home.

WHAT YOU MUST DO FOR WARRANTY SERVICE:

Please do not return your product to the retailer

Instead, return your product to the JVC authorized service center nearest you. If shipping the product to the service center, please be sure to package it carefully, preferably in the original packaging, and include a brief description of the problem(s). Please call 1-800-252-5722 to locate the nearest JVC authorized service center. Service locations can also be obtained from our website http://www.jvc.com. If your product qualifies for in-home service, the service representative will require clear access to the product.

If you have any questions concerning your JVC Product, please contact our Customer Care Center at 800-252-5722

WHAT IS NOT COVERED:

This limited warranty provided by JVC does not cover:

1. Products which have been subject to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, or if repaired or serviced by anyone other than a service facility authorized by JVC to render such service, or if affixed to any attachment not provided with the products, or if the model or serial number has been altered, tampered with, defaced or removed;
2. Initial installation, installation and removal from cabinets or mounting systems.
3. Operational adjustments covered in the Owner's Manual, normal maintenance, video and audio head cleaning;
4. Damage that occurs in shipment, due to act of God, and cosmetic damage;
5. Signal reception problems and failures due to line power surge;
6. User Removal Memory Devices/Video Pick-up Tubes/CCD Image Sensors are covered for 90 days from the date of purchase;
7. Accessories;
8. Batteries (except that Rechargeable Batteries are covered for 90 days from the date of purchase);
9. Products used for commercial purposes, including, but not limited to rental.
10. Loss of data resultant from malfunction of hard drive or other data storage device;

There are no express warranties except as listed above.

THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN.

JVC SHALL NOT BE LIABLE FOR ANY LOSS OF USE OF THE PRODUCT, INCONVENIENCE, OR ANY OTHER DAMAGES, WHETHER DIRECT, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, WITHOUT LIMITATION, DAMAGE TO TAPES, RECORDS OR DISCS) RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion of incidental or consequential damages or limitations on how long an implied warranty lasts, so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

JVC AMERICAS CORP.
1700 Valley Road, Wayne, New Jersey 07470
http://www.jvc.com

REFURBISHED PRODUCTS CARRY A SEPARATE WARRANTY, THIS WARRANTY DOES NOT APPLY. FOR DETAIL OF REFURBISHED PRODUCT WARRANTY, PLEASE REFER TO THE REFURBISHED PRODUCT WARRANTY INFORMATION PACKAGED WITH EACH REFURBISHED PRODUCT.

For customer use:

Enter below the Model No. and Serial No. which is located either on the rear, bottom or side of the cabinet. Retain this information for future reference.

Model No. : _____ Serial No. : _____

Purchase date : _____ Name of dealer : _____

JVC COMPANY OF AMERICA
Division of JVC Americas Corp.
1700 Valley Road
Wayne, New Jersey, 07470

Printed in China

A94F5UH/A94F6UH
1EMN24860 ★★★★★

Other ManualsLib Projects

www.manualslib.com

www.manualslib.de

www.manualslib.es

www.manualslib.fr

www.manualslib.nl

www.manualslib.mx

www.manualslib.tech 30+ Languages